
INSITE for Cense Installation Instructions for Windows 7 - 32bit Only

1) Select Browse CENSE from Autorun Menu
2) Change properties of setup.exe file as shown below. Then run it



3) Click **Next** at the Welcome screen
4) Click **Yes** at the License Agreement
5) Click **Next** at the Information screen

6) Click **Next** at the Destination Location
7) Click **Next** at the Components screen
8) Make sure '**Direct Serial**' is selected and Click **Next** at the Application Settings

9) Click **Next** at the Communication Port Settings
10) Click **Next** at Start Copying files
11) Click **Finish** when install completes

12) Create shortcuts to the application. C:\Intelect\CENSE\BIN\INSCENSE.exe