

## INSITE 8.2.X Error Code List

FileName	Error Number	Error Description
ActuatorDiagnosticTestResources_EN.xml	17600	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17601	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17602	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17603	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17604	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17605	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17606	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17607	An Internal Error has occurred in INSITE Program.
ActuatorDiagnosticTestResources_EN.xml	17608	INSITE was unable to determine if the test is available to run on this ECM..
ActuatorDiagnosticTestResources_EN.xml	17609	INSITE failed to perform the requested ECM operation.
ActuatorDiagnosticTestResources_EN.xml	17610	INSITE was unable to determine if the test is enabled to run on this ECM..
ActuatorDiagnosticTestResources_EN.xml	17611	Unable to read test token.
ActuatorDiagnosticTestResources_EN.xml	17612	Unable to write to test token.
ActuatorDiagnosticTestResources_EN.xml	17641	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17614	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17615	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17616	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17617	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17618	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17619	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17620	An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17621	INSITE failed to perform the requested ECM operation.
ActuatorDiagnosticTestResources_EN.xml	17622	INSITE failed to perform the requested ECM operation.
ActuatorDiagnosticTestResources_EN.xml	17623	An internal error has occurred in the INSITE program.
ActuatorDiagnosticTestResources_EN.xml	17624	INSITE has detected the PC is running low on system resources.
ActuatorDiagnosticTestResources_EN.xml	17625	An internal error has occurred in the INSITE program.
ActuatorDiagnosticTestResources_EN.xml	17626	An internal error has occurred in the INSITE program.
ActuatorDiagnosticTestResources_EN.xml	17627	An internal error has occurred in the INSITE program.
ActuatorDiagnosticTestResources_EN.xml	17628	Failed to determine whether test is enabled in the ECM.

ActuatorDiagnosticTestResources_EN.xml	17629 An unidentified error occurred in the ECM Test "Actuator Diagnostic Tests".
ActuatorDiagnosticTestResources_EN.xml	17630 Failed to find logic events.
ActuatorDiagnosticTestResources_EN.xml	17631 Failed to get the pointer to monitors.
ActuatorDiagnosticTestResources_EN.xml	17632 Failed to get the monitor id.
ActuatorDiagnosticTestResources_EN.xml	17633 Failed to get the monitor service.
ActuatorDiagnosticTestResources_EN.xml	17634 Failed to get the connection point server.
ActuatorDiagnosticTestResources_EN.xml	17635 Failed to add module to monitors.
ActuatorDiagnosticTestResources_EN.xml	17636 Failed to add parameter to monitors.
ActuatorDiagnosticTestResources_EN.xml	17637 Failed to subscribe events.
ActuatorDiagnosticTestResources_EN.xml	17638 Failed to unsubscribe events.
ActuatorDiagnosticTestResources_EN.xml	17639 An error occurred while invoking unadvise.
ActuatorDiagnosticTestResources_EN.xml	17640 An error occurred while stopping the monitors.
ActuatorDiagnosticTestResources_EN.xml	17642 The current test selection is invalid.
ActuatorDiagnosticTestResources_EN.xml	17643 INSITE has detected the PC is running low on system resources.
ActuatorDiagnosticTestResources_EN.xml	17644 Failed to determine whether test is enabled in the ECM.
AdvancedDataContainerResources_EN.xml	17501 An internal error has occurred in the INSITE program.
AdvancedDataContainerResources_EN.xml	17502 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17503 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17504 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17505 An internal error has occurred in the INSITE program.
AdvancedDataContainerResources_EN.xml	17506 An internal error has occurred in the INSITE program.
AdvancedDataContainerResources_EN.xml	17507 An internal error has occurred in the INSITE program.
AdvancedDataContainerResources_EN.xml	17508 An internal error has occurred in the INSITE program.
AdvancedDataContainerResources_EN.xml	17509 An internal error has occurred in the INSITE program.
AdvancedDataContainerResources_EN.xml	17002 The additional information feature could not be closed.
AdvancedDataContainerResources_EN.xml	17003 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17004 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17005 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17006 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17007 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17008 INSITE was unable to detect a required component.

AdvancedDataContainerResources_EN.xml	17009 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17010 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17011 INSITE was unable to determine the ECM type.
AdvancedDataContainerResources_EN.xml	17012 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17013 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17014 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17015 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17016 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17017 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17018 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17019 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17020 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17021 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17022 INSITE was unable to create a required component.
AdvancedDataContainerResources_EN.xml	17023 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17024 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17025 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17026 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17027 INSITE was unable to detect a required component.
AdvancedDataContainerResources_EN.xml	17028 INSITE was unable to convert a required file.
AdvancedDataContainerResources_EN.xml	17029 INSITE was unable to convert a required file.
AdvancedDataContainerResources_EN.xml	17030 An internal error has occurred in the INSITE program.
AEMLogViewerResources_EN.xml	35050 There has been an error during the transfer of the Engine Shutdown Log from the ECM. Please select Help for more information.
AEMLogViewerResources_EN.xml	35051 There has been an error during the reset of the Engine Shutdown Log from the ECM. Please select Help for more information.
AEMLogViewerResources_EN.xml	35052 An Internal Error has occurred in INSITE Program.
AEMLogViewerResources_EN.xml	35053 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35054 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35055 An Internal Error has occurred in INSITE Program during feature page initialization.

AEMLogViewerResources_EN.xml	35056 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35057 An Internal Error has occurred in INSITE Program while saving the log.
AEMLogViewerResources_EN.xml	35058 An Internal Error has occurred in INSITE Program while saving the log.
AEMLogViewerResources_EN.xml	35059 INSITE was unable to determine if the feature is supported by the application
AEMLogViewerResources_EN.xml	35060 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35061 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35062 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35063 An Internal Error has occurred in INSITE Program while unloading feature page.
AEMLogViewerResources_EN.xml	35064 An Internal Error has occurred in INSITE Program while unloading feature page.
AEMLogViewerResources_EN.xml	35065 An Internal Error has occurred in INSITE Program while updating log download progress.
AEMLogViewerResources_EN.xml	35066 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35067 An Internal Error has occurred in INSITE Program during feature page initialization.
AEMLogViewerResources_EN.xml	35068 An Internal Error has occurred in INSITE Program while displaying help.
AEMLogViewerResources_EN.xml	35071 INSITE has detected the PC is running low on system resources.
AEMLogViewerResources_EN.xml	35072 An Internal Error has occurred in INSITE Program.
AEMLogViewerResources_EN.xml	35073 Failed to get query the data service.
AEMLogViewerResources_EN.xml	35074 Failed to read token from ECM.
AEMLogViewerResources_EN.xml	35075 Failed to create thread.
AEMLogViewerResources_EN.xml	35076 Failed to read the feature enable token.
AEMLogViewerResources_EN.xml	35077 Failed to reset the logs.
AEMLogViewerResources_EN.xml	35078 Failed to fire event to page.
AEMLogViewerResources_EN.xml	35079 Failed to publish events.
AEMLogViewerResources_EN.xml	35080 Failed to unpublish events.
AEMLogViewerResources_EN.xml	35081 Failed to load licences for feature.
AEMLogViewerResources_EN.xml	35082 INSITE has detected the PC is running low on system resources.
AEMLogViewerResources_EN.xml	35083 Error during initializing the logic.
AEMLogViewerResources_EN.xml	35084 Error during unload of the logic.
AEMLogViewerResources_EN.xml	35085 Failed to initialize log info.
AEMLogViewerResources_EN.xml	35086 Error while accessing safearray.
AEMLogViewerResources_EN.xml	35087 Error while checking operation response.
AEMLogViewerResources_EN.xml	35088 Error while cancelling the get log operation.

AEMLogViewerResources_EN.xml	35089 Failed to read the log array.
AEMLogViewerResources_EN.xml	35090 Failed to merge the log arrays.
AEMLogViewerResources_EN.xml	35091 Failed to sort the merged log arrays.
AEMLogViewerResources_EN.xml	35092 Failed to make the log data collection.
AEMLogViewerResources_EN.xml	35093 An Internal Error has occurred in INSITE Program while unloading feature page.
AEMLogViewerResources_EN.xml	35094 An Internal Error has occurred in INSITE Program while saving logs.
AEMLogViewerResources_EN.xml	35095 An Internal Error has occurred in INSITE Program while saving logs.
AEMLogViewerResources_EN.xml	35096 An Internal Error has occurred in INSITE Program.
AEMLogViewerResources_EN.xml	35097 An Internal Error has occurred in INSITE Program while reading logs.
AEMLogViewerResources_EN.xml	35098 An Internal Error has occurred in INSITE Program while getting logs.
AEMLogViewerResources_EN.xml	35099 Failed to create thread.
AEMLogViewerResources_EN.xml	35100 Failed to kill thread.
AEMLogViewerResources_EN.xml	35101 Failed to Initialize thread management.
AEMLogViewerResources_EN.xml	35102 Failed to determine if reset is valid.
AEMLogViewerResources_EN.xml	35103 Failed to get logs.
AEMLogViewerResources_EN.xml	35104 Failed to write token to ECM.
AEMLogViewerResources_EN.xml	35106 Failed to retrieve buffered data.
AEMLogViewerResources_EN.xml	35107 Failed to retrieve the total number of log records.
AEMLogViewerResources_EN.xml	35108 Failed to initialize Logic
AEMLogViewerResources_EN.xml	35109 Failed to initialize splitter control
AEMLogViewerResources_EN.xml	35150 There has been an error during the transfer of the AEM Enhanced Fault Snapshot Log from the ECM.
AEMLogViewerResources_EN.xml	35151 There has been an error during the reset of the AEM Enhanced Fault Snapshot Log from the ECM.
AEMLogViewerResources_EN.xml	35350 There has been an error during the transfer of the AEM Trend Log from the ECM.
AEMLogViewerResources_EN.xml	35351 There has been an error during reset of the AEM Trend Log from the ECM.
AEMLogViewerResources_EN.xml	35112 There has been an error while reading the log data. Please select Help for more information
AEMLogViewerResources_EN.xml	35113 An Internal Error has occurred in INSITE Program while loading WorkOrder's Image
AEMLogViewerResources_EN.xml	35200 There has been an error during the transfer of the AEM Start Stop Log from the ECM.
AEMLogViewerResources_EN.xml	35201 There has been an error during reset of the AEM Start Stop Log from the ECM.
AftertreatmentHistoryResources_EN.xml	18900 An Internal Error has occurred in INSITE Program.
AftertreatmentHistoryResources_EN.xml	18901 Failed to get query the data service.
AftertreatmentHistoryResources_EN.xml	18902 Failed to read token from ECM.
AftertreatmentHistoryResources_EN.xml	18903 Failed to create thread.
AftertreatmentHistoryResources_EN.xml	18904 Failed to read the feature enable token.

AftertreatmentHistoryResources_EN.xml	18905 INSITE has detected the PC is running low on system resources.
AftertreatmentHistoryResources_EN.xml	18906 Error during initializing the logic.
AftertreatmentHistoryResources_EN.xml	18907 Error during unload of the logic.
AftertreatmentHistoryResources_EN.xml	18908 Failed to initialize log info.
AftertreatmentHistoryResources_EN.xml	18909 Error while accessing safearray.
AftertreatmentHistoryResources_EN.xml	18910 Failed to read the log array.
AftertreatmentHistoryResources_EN.xml	18911 Failed to make the log data collection.
AftertreatmentHistoryResources_EN.xml	18912 Failed to retrieve buffered data.
AftertreatmentHistoryResources_EN.xml	18950 An Internal Error has occurred in INSITE Program.
AftertreatmentHistoryResources_EN.xml	18951 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18952 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18953 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18954 An Internal Error has occurred in INSITE Program while saving the log.
AftertreatmentHistoryResources_EN.xml	18955 INSITE was unable to determine if the feature is supported by the application
AftertreatmentHistoryResources_EN.xml	18956 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18957 An Internal Error has occurred in INSITE Program while unloading feature page.
AftertreatmentHistoryResources_EN.xml	18958 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18959 An Internal Error has occurred in INSITE Program while unloading feature page.
AftertreatmentHistoryResources_EN.xml	18960 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18961 An Internal Error has occurred in INSITE Program during feature page initialization.
AftertreatmentHistoryResources_EN.xml	18962 An Internal Error has occurred in INSITE Program while displaying help.
AftertreatmentHistoryResources_EN.xml	18963 An Internal Error has occurred in INSITE Program while saving logs.
AftertreatmentHistoryResources_EN.xml	18964 INSITE has detected the PC is running low on system resources.
AftertreatmentHistoryResources_EN.xml	18965 An Internal Error has occurred in INSITE Program.
AftertreatmentHistoryResources_EN.xml	18966 An Internal Error has occurred in INSITE Program while getting logs. The Aftertreatment History log data could not be read from the module.
AftertreatmentHistoryResources_EN.xml	18967 Please select Refresh after clicking OK.
AFTMaintenanceGTIS45Resources_EN.xml	35601 Unknown error occurred in page.
AntiTheftProtectionGTIS45Resources_EN.xml	19001 An Internal Error has occurred in INSITE Program.
AntiTheftProtectionGTIS45Resources_EN.xml	19002 Error during initializing the logic.
AntiTheftProtectionGTIS45Resources_EN.xml	19003 Error occurred while loading the licenses.

AntiTheftProtectionGTIS45Resources_EN.xml	19004 Error during unload of the logic.
AntiTheftProtectionGTIS45Resources_EN.xml	19005 Failed to read the feature enable token.
AntiTheftProtectionGTIS45Resources_EN.xml	19006 Error occurred while reading a token from ECM.
AntiTheftProtectionGTIS45Resources_EN.xml	19007 Error occurred while writing a token to ECM.
AntiTheftProtectionGTIS45Resources_EN.xml	19008 Error occurred while changing the password.
AntiTheftProtectionGTIS45Resources_EN.xml	19009 Error occurred while disabling the password.
AntiTheftProtectionGTIS45Resources_EN.xml	19010 Error occurred while verifying a password.
AntiTheftProtectionGTIS45Resources_EN.xml	19011 Error occurred while changing Anti-theft State
AntiTheftProtectionGTIS45Resources_EN.xml	19012 Error occurred while adding a new password.
AntiTheftProtectionGTIS45Resources_EN.xml	19051 An Internal Error has occurred in INSITE Program during feature page initialization.
AntiTheftProtectionGTIS45Resources_EN.xml	19052 An internal error occurred during unloading of the Anti-theft Protection special feature
AntiTheftProtectionGTIS45Resources_EN.xml	19053 INSITE was unable to determine if the feature is supported by the application
AntiTheftProtectionGTIS45Resources_EN.xml	19054 Error occurred while checking for licenses
AntiTheftProtectionGTIS45Resources_EN.xml	19055 Error occurred while determining whether Auto Lock Mode is enabled or not
AntiTheftProtectionGTIS45Resources_EN.xml	19056 Error occurred while determining Engine Lock State.
AntiTheftProtectionGTIS45Resources_EN.xml	19057 Error occurred while reading Anti-theft protection feature's enable status.
AntiTheftProtectionGTIS45Resources_EN.xml	19058 Error occurred while reading a parameter.
AntiTheftProtectionGTIS45Resources_EN.xml	19059 Error occurred while writing a parameter
AntiTheftProtectionGTIS45Resources_EN.xml	19060 Error occurred while changing enable state of AutoLock Mode.
AntiTheftProtectionGTIS45Resources_EN.xml	19061 Error occurred while adding a new password.
AntiTheftProtectionGTIS45Resources_EN.xml	19062 Error occurred while changing the password
AntiTheftProtectionGTIS45Resources_EN.xml	19063 Error occurred while verifying Password
AntiTheftProtectionGTIS45Resources_EN.xml	19064 Error occurred while changing Anti-theft protection feature status.
AntiTheftProtectionGTIS45Resources_EN.xml	19065 Error occurred in FlexGrid helper
AntiTheftProtectionGTIS45Resources_EN.xml	19066 Error occurred while dealing with User Interface element of feature window
AntiTheftProtectionGTIS45Resources_EN.xml	19067 There are insufficient resources to complete requested operation.
AntiTheftProtectionResources_EN.xml	18600 Unknown error in Anti-Theft Protection.
AntiTheftProtectionResources_EN.xml	18602 Error while writing to the ECM.
AntiTheftProtectionResources_EN.xml	18603 Error while retrieving the status of the Anti-Theft Protection components from the ECM.
AntiTheftProtectionResources_EN.xml	18604 Error while reading from the ECM.
AntiTheftProtectionResources_EN.xml	18605 Cannot enable the password in the ECM without entering a new password.
AntiTheftProtectionResources_EN.xml	18601 Error while initializing the logic for Anti-theft Protection.
AntiTheftProtectionResources_EN.xml	18606 Error while firing an event from the logic.
AntiTheftProtectionResources_EN.xml	18607 Internal error accessing update results.
AntiTheftProtectionResources_EN.xml	18608 Feature Initialization failed.
AntiTheftProtectionResources_EN.xml	18609 Internal interface query failed.
AntiTheftProtectionResources_EN.xml	18610 Internal messaging operation failed.
AntiTheftProtectionResources_EN.xml	18611 Internal error accessing dialog element.
AntiTheftProtectionResources_EN.xml	18612 Internal error beginning the status update process.
AntiTheftProtectionResources_EN.xml	18613 Internal error beginning the password validation process.
AntiTheftProtectionResources_EN.xml	18614 Internal error writing to the ECM.
AntiTheftProtectionResources_EN.xml	You cannot perform this operation, either because you do not have the appropriate tool level 18615 or because the ECM is password protected.
AntiTheftProtectionResources_EN.xml	18616 Internal error while determining whether ECM writes are permitted.
AntiTheftProtectionResources_EN.xml	18617 Unable to complete the current operation because the system is busy.
AntiTheftProtectionResources_EN.xml	18618 Error while initiating a thread to perform the current operation.
AntiTheftProtectionResources_EN.xml	18619 Vehicle Anti-theft is unavailable for this calibration.
AntiTheftProtectionResources_EN.xml	18620 Vehicle Anti-theft Automatic Mode is unavailable for this calibration.
AntiTheftProtectionResources_EN.xml	Internal error while determining whether the adjustables are available for the current 18621 calibration.

AntiTheftProtectionResources_EN.xml	18622 Internal error while setting up the data for printing.
AntiTheftProtectionResources_EN.xml	18623 Internal error while attempting to display the print preview.
AntiTheftProtectionResources_EN.xml	18624 Internal error while attempting to print.
AntiTheftProtectionResources_EN.xml	18625 Internal error reading engine speed.
AntiTheftProtectionResources_EN.xml	18626 This feature cannot be adjusted because: Immobilizer = Enable. An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20730 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20731 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20732 Failed to publish events.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20733 Failed to unpublish events.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20734 Failed to initialize the ECM.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20735 An unidentified error occurred in starting the test.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20736 An unidentified error occurred in stopping the test.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20737 Failed to get the thread facility.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20738 Failed to request a new thread.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20739 INSITE was unable to determine if the test is available on this ECM.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20740 INSITE failed to perform to perform ECM operation.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20741 The test is not supported by the current calibration.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20742 Failed to read Test token.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20743 Failed to write Test token.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20744 Failed to find logic events.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20745 Failed to get monitors pointer.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20746 Failed to get monitor ID.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20747 Failed to get monitor service.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20748 Failed to get connection point server.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20749 Failed to add modules to monitor.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20750 Failed to add parameters to monitor.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20751 Failed to subscribe the event.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20752 Failed to unsubscribe the event.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20753 An unidentified error occurred in invoking Advise.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20754 An unidentified error occurred in invoking Unadvise.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20755 An unidentified error occurred in stopping the monitor.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20756 Out of memory.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20757 Invalid Test Mode.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20758 Invalid Response Code.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20759 Error in firing a message.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20760 Error in starting the monitor.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20761 Error in stopping the monitor.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20762 Error in reading a token.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20763 Error in writing a token.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20830 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20831 Test".



ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20832 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20833 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20834 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20835 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20836 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20837 INSITE failed to Start the Test.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20838 INSITE failed to Stop the Test.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20839 An internal error has occurred in the INSITE program.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20840 An internal error has occurred in the INSITE program.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20841 The test is not supported by the current calibration.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20842 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20843 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20844 INSITE has detected the PC is running low on system resources.
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20845 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20846 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Injector and SOV Override 20847 Test".
ATInjectorSOVOverrideGTIS45Resources_EN.xml	20848 INSITE failed to launch the help.
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter 20800 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter 20801 Regeneration".
ATRResources_EN.xml	20802 Failed to publish events.
ATRResources_EN.xml	20803 Failed to unpublish events.
ATRResources_EN.xml	20804 Failed to subscribe events.
ATRResources_EN.xml	20805 Failed to subscribe events.
ATRResources_EN.xml	20806 Failed to get the thread facility.
ATRResources_EN.xml	20807 Failed to request a new thread.
ATRResources_EN.xml	20808 Failed to get thread callback
ATRResources_EN.xml	20809 INSITE was unable to determine if the test is available on this ECM.
ATRResources_EN.xml	20810 Failed to find logic events
ATRResources_EN.xml	20811 Failed to get monitors pointer.
ATRResources_EN.xml	20812 Failed to get monitor ID.
ATRResources_EN.xml	20813 Failed to get monitor service.
ATRResources_EN.xml	20814 Failed to get connection point server.
ATRResources_EN.xml	20815 Failed to add modules to monitor.
ATRResources_EN.xml	20816 Failed to add parameters to monitor.
ATRResources_EN.xml	20817 An error occurred while invoking Advise.
ATRResources_EN.xml	20818 An error occurred while invoking UnAdvise.

ATRResources_EN.xml	20819 An unidentified error occurred in starting the test.
ATRResources_EN.xml	20820 An unidentified error occurred in stopping the test.
ATRResources_EN.xml	20821 An error occurred while writing a token.
ATRResources_EN.xml	20822 An error occurred while writing a token.
ATRResources_EN.xml	20823 An error occurred while stopping the test.
ATRResources_EN.xml	20824 An Invalid Response Code has occurred.
ATRResources_EN.xml	20825 An Invalid Registry path.
ATRResources_EN.xml	20826 Unable to load string in the ECM Test "Aftertreatment Diesel Particulate Filter Regeneration
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20900 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20901 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20902 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20903 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20904 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20905 Regeneration".
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20906 Regeneration".
ATRResources_EN.xml	20907 INSITE failed to Start the Test.
ATRResources_EN.xml	20908 INSITE failed to Stop the Test.
ATRResources_EN.xml	20909 An internal error has occurred in the INSITE program.
ATRResources_EN.xml	20910 An internal error has occurred in the INSITE program.
ATRResources_EN.xml	20911 An internal error has occurred in the INSITE program.
ATRResources_EN.xml	An unidentified error occurred in the ECM Test "Aftertreatment Diesel Particulate Filter
ATRResources_EN.xml	20912 Regeneration".
ATRResources_EN.xml	20913 Unable to load string in the ECM Test "Aftertreatment Diesel Particulate Filter Regeneration
CalibrationSelectionResources_EN.xml	27001 Insufficient free space exists on the destination drive. Upgrade will be aborted.
CalibrationSelectionResources_EN.xml	27002 An error occurred while attempting to locate the destination drive.
CalibrationSelectionResources_EN.xml	27003 The destination drive is the same as the source drive. Upgrade will be aborted.
CalibrationSelectionResources_EN.xml	27004 An error occurred while attempting upgrade the engine programs on the destination drive.
CalibrationSelectionResources_EN.xml	27005 An error occurred while attempting purge the engine programs on the selected drive.
CalibrationSelectionResources_EN.xml	27500 Unexpected error in Calibration Selection.
CalibrationSelectionResources_EN.xml	27501 Writing the data plate back to the ECM failed.
CalibrationSelectionResources_EN.xml	27502 Creation of the Calibration Download component failed.
CalibrationSelectionResources_EN.xml	27503 Initializing the Calibration Download component failed. (Failed to Advise events.)
CalibrationSelectionResources_EN.xml	27504 Calibration Selection failed to glean the connection parameters from Connection Manager.
CalibrationSelectionResources_EN.xml	27505 Calibration Selection failed to set a Calibration Download parameter.
CalibrationSelectionResources_EN.xml	27506 Calibration Download does not support the connected ECM.
CalibrationSelectionResources_EN.xml	27507 Calibration Selection was unable to attain an exclusive lock from ECMServices.
CalibrationSelectionResources_EN.xml	27508 No response from ECM
CalibrationSelectionResources_EN.xml	27509 Calibration Selection was unable to release its exclusive lock.
CalibrationSelectionResources_EN.xml	27510 Calibration Selection was unable to request an ECM disconnect from Connection Manager.
CalibrationSelectionResources_EN.xml	27511 Calibration Selection was unable to write the selected Power Curve value.
CalibrationSelectionResources_EN.xml	27512 Calibration Selection was unable to unadvise calibration download events.
CalibrationSelectionResources_EN.xml	27513 Calibration Selection was unable to uncompress the calibration file.
CalibrationSelectionResources_EN.xml	The Master Password has not been validated for the ECM. A Calibration cannot be
CalibrationSelectionResources_EN.xml	27514 downloaded without the password.
CalibrationSelectionResources_EN.xml	Calibration Selection was unable to complete reading the data plate. Some information may
CalibrationSelectionResources_EN.xml	27515 be missing.
CalibrationSelectionResources_EN.xml	27516 Calibration Selection was unable to determine the module connection parameters.
CalibrationSelectionResources_EN.xml	27517 Calibration Selection was unable to reconnect to the module.
CalibrationSelectionResources_EN.xml	INSITE cannot download the calibration at this time because INSITE was unable to locate a
CalibrationSelectionResources_EN.xml	27006 valid calibration transfer license.
CalibrationSelectionResources_EN.xml	INSITE cannot download the calibration at this time because INSITE is not currently
CalibrationSelectionResources_EN.xml	27007 connected to an ECM.

CalibrationSelectionResources_EN.xml	27008 Connected ECM contains a calibration for XXX. Selected calibration is for YYY. Please Boot the ECM and attempt the calibration download again.
CalibrationSelectionResources_EN.xml	27009 INSITE cannot download the calibration at this time because INSITE cannot currently write the ECM.
CalibrationSelectionResources_EN.xml	27010 INSITE cannot download the calibration because it is locked with a Master Password. Please go to Tools ->ECM Passwords to enter the Master password.
CalibrationSelectionResources_EN.xml	27010 INSITE cannot download the calibration because it is locked with a Master Password. Please go to Tools ->ECM Passwords to enter the Master password/ Reconnect INSITE using the Master password.
CalibrationSelectionResources_EN.xml	27012 INSITE cannot download the calibration at this time because INSITE is unable to calibrate a virtual ECM.
CalibrationSelectionResources_EN.xml	27013 INSITE cannot download the calibration at this time because a non-CENSE connection is already active.
CalibrationSelectionResources_EN.xml	27011 INSITE cannot download the calibration at this time because the user does not have sufficient rights.
CalibrationSelectionResources_EN.xml	27014 A parameter not present in the calibration failed to restore.
CalibrationSelectionResources_xx.xml	27020 An error occurred while attempting to copy the calibration
CalibrationSelectionResources_xx.xml	27021 The selected calibration is not compatible to the connected ECM and cannot be downloaded
CentinelOperationalTestResources_EN.xml	21000 Failed to unpublish published events.
CentinelOperationalTestResources_EN.xml	21001 An unidentified error occurred in the ECM Test "Centinel Operational Test".
CentinelOperationalTestResources_EN.xml	21002 Failed to subscribe to necessary events. Centinel Operational Test may behave improperly
CentinelOperationalTestResources_EN.xml	21003 Failed to publish necessary events. Centinel Operational Test may behave improperly.
CentinelOperationalTestResources_EN.xml	21004 Failed to acquire necessary Centinel Operational Test Helper.
CentinelOperationalTestResources_EN.xml	21005 Failed to load a necessary resource.
CentinelOperationalTestResources_EN.xml	21006 Unable to start the Centinel Operational Test.
CentinelOperationalTestResources_EN.xml	21007 INSITE failed to initialize Monitoring of parameters.
CentinelOperationalTestResources_EN.xml	21008 An internal error has occurred in the INSITE program.
CentinelOperationalTestResources_EN.xml	21009 INSITE failed to perform the requested ECM operation.
CentinelOperationalTestResources_EN.xml	21010 An unidentified error occurred in the ECM Test "Centinel Operational Test".
CentinelOperationalTestResources_EN.xml	21011 Failed to detect type of Test.
CentinelOperationalTestResources_EN.xml	21012 Unable to properly stop the Centinel Operational Test.
CentinelOperationalTestResources_EN.xml	21013 INSITE failed to stop Monitoring of parameters.
CentinelOperationalTestResources_EN.xml	21014 Failed to write start token.
CentinelOperationalTestResources_EN.xml	21015 Failed to perform Actuator Cycling.
CentinelOperationalTestResources_EN.xml	21016 Operation response code is not Success. Test shall not start.
ConnectionManagerResources_EN.xml	5000 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5001 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5002 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5003 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5004 An internal error has occurred in the INSITE program.

ConnectionManagerResources_EN.xml	5005 No ECM connection was detected.
ConnectionManagerResources_EN.xml	5006 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5007 No ECM connection was detected.
ConnectionManagerResources_EN.xml	5008 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5009 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5010 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5011 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5012 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5013 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5014 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5015 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5016 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5017 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5018 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5019 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5020 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5021 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5022 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5023 A connection to the ECM cannot be established or has been lost.
ConnectionManagerResources_EN.xml	5024 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5025 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5026 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5027 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5028 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5029 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5030 An internal error has occurred in the INSITE program.

ConnectionManagerResources_EN.xml	5031 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5032 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5033 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5034 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5035 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5036 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5037 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5038 An invalid password has been detected. Please re-enter the correct password.
ConnectionManagerResources_EN.xml	5039 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5040 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5041 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5042 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5043 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5044 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5045 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5046 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5047 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5048 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5049 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5050 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5051 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5052 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5053 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5054 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5055 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5056 An internal error has occurred in the INSITE program.

ConnectionManagerResources_EN.xml	5057 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5058 RESERVED
ConnectionManagerResources_EN.xml	5059 RESERVED
ConnectionManagerResources_EN.xml	5060 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5061 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5062 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5063 An internal error has occurred in the INSITE program. Please verify the port connections.
ConnectionManagerResources_EN.xml	5064 An internal error has occurred in the INSITE program. Please verify the port connections.
ConnectionManagerResources_EN.xml	5065 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5066 No connection to the ECM was established or detected.
ConnectionManagerResources_EN.xml	5067 An internal error has occurred in the INSITE program. Verify that the keyswitch is in the ON position and the datalink is connected.
ConnectionManagerResources_EN.xml	5068 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5069 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5070 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5071 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5072 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5073 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5074 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5075 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5076 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5077 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5078 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5079 An internal error has occurred in the INSITE program. INSITE has detected some ECM(s) are ROM-booted and must be recalibrated. INSITE has detected the following ECM(s) are currently calibrated:

ConnectionManagerResources_EN.xml	<p>CM850 (0) (Primary)  CM850 (1) (Secondary)  INSITE has detected the following ECM(s) are ROM-booted:  5080 CM850 (46)</p>
ConnectionManagerResources_EN.xml	<p>INSITE has detected some ECM(s) have an invalid Footprint and must be recalibrated.  INSITE has detected the following ECM(s) are currently calibrated:  CM850 (0) (Primary)  CM850 (1) (Secondary)  INSITE has detected the following ECM(s) are ROM-booted:  5081 CM850 (46)</p>
ConnectionManagerResources_EN.xml	5082 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5083 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5084 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5085 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5086 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5087 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	5088 An internal error has occurred in the INSITE program.
ConnectionManagerResources_EN.xml	<p>INSITE has detected some ECM(s) are in an invalid state.  INSITE has detected the following ECM(s) are currently calibrated:  CM850 (0) (Primary)  CM850 (1) (Secondary)  INSITE has detected the following ECM(s) are in an invalid state:  5089 CM850 (46)</p>
ConnectionManagerResources_EN.xml	5090 Enter a valid Master password and recalibrate the ECM. The ECM is in an invalid state.
ConnectionManagerResources_EN.xml	<p>INSITE has detected some ECM(s) are Seeded and must be recalibrated.  INSITE has detected the following ECM(s) are currently calibrated:  CM850 (0) (Primary)  CM850 (1) (Secondary)  INSITE has detected the following ECM(s) are Seeded:  5091 CM850 (46)</p>
ConnectionManagerResources_EN.xml	<p>INSITE has detected some ECM(s) cannot operate and must be recalibrated.  INSITE has detected the following ECM(s) are currently calibrated:  &lt;ECM NAME&gt; &lt;Service_ECM_Marketing_Name&gt;]  INSITE has detected the following ECM(s) have Incompatible Calibrations:  5092 &lt;ECM Name&gt; [&lt;Source Address&gt;]</p>
ConnectionManagerResources_EN.xml	5100 An internal error has occurred in the MLS Logic.
ConnectionManagerResources_EN.xml	5200 Communication between the computer and the datalink adapter has been lost.
ConnectionManagerResources_EN.xml	5201 Communication between the datalink adapter and the ECM has been lost.
ConnectionManagerResources_EN.xml	5202 Communication between the computer and the datalink adapter could not be established.

ConnectionManagerResources_EN.xml	5204 Communication between the datalink adapter and the ECM could not be established
ConnectionManagerResources_EN.xml	5205 Communication between the datalink adapter and the Smart Device has been lost.
CylinderCutoutResources_EN.xml	20000 An unidentified error occurred in the ECM Test "Cylinder Cutout Test".
CylinderCutoutResources_EN.xml	20001 An unidentified error occurred in the ECM Test "Cylinder Cutout Test".
CylinderCutoutResources_EN.xml	20002 Failed to publish necessary events. Cylinder Cutout Test may behave improperly.
CylinderCutoutResources_EN.xml	20003 Failed to unpublish published events.
CylinderCutoutResources_EN.xml	20004 Failed to acquire necessary threading resources.
CylinderCutoutResources_EN.xml	20005 Failed to acquire necessary kernel resources.
CylinderCutoutResources_EN.xml	20006 Could not request the ECM to start test.
CylinderCutoutResources_EN.xml	20007 Could not request the ECM to stop test.
CylinderCutoutResources_EN.xml	20008 Unexpected error while posting internal advisories.
CylinderCutoutResources_EN.xml	20009 Failed to acquire a requested thread.
CylinderCutoutResources_EN.xml	20010 An error occurred during an internal operation on an XML DOM or DOC object.
CylinderCutoutResources_EN.xml	20011 Failed to post internal advisory.
CylinderCutoutResources_EN.xml	20012 Failure while requesting data from ECM Services.
CylinderCutoutResources_EN.xml	20013 Failure while writing data to ECM Services.
CylinderCutoutResources_EN.xml	20014 The ECM Test "Cylinder Cutout Test" has not been initialized.
CylinderCutoutResources_EN.xml	20015 Failed to initiate an operation to collect ECM data.
CylinderCutoutResources_EN.xml	20016 The engine must be running before starting this test.
CylinderCutoutResources_EN.xml	20030 An unidentified error occurred in the ECM Test "Cylinder Cutout Test".
CylinderCutoutResources_EN.xml	20031 An unidentified error occurred in the ECM Test "Cylinder Cutout Test".
CylinderCutoutResources_EN.xml	20032 Failed to subscribe to necessary events. Cylinder Cutout Test may behave improperly.
CylinderCutoutResources_EN.xml	20033 Failed to unsubscribe from necessary events.
CylinderCutoutResources_EN.xml	20034 Failed to acquire necessary Cylinder Cutout.
CylinderCutoutResources_EN.xml	20035 Failed to start test.
CylinderCutoutResources_EN.xml	20036 Failed to stop possible test in progress.
CylinderCutoutResources_EN.xml	20037 Failed to stop possible test in progress while closing ECM Diagnostic Tests.
CylinderCutoutResources_EN.xml	20038 Failed to update Engine Statistics window. Displayed values may be invalid.
CylinderCutoutResources_EN.xml	20039 Unspecified error occurred while initializing test user interface.
CylinderCutoutResources_EN.xml	20040 Failed to load a necessary resource.
CylinderCutoutResources_EN.xml	20041 Unspecified error occurred while initializing test user interface.
CylinderCutoutResources_EN.xml	20042 Unexpected failure of user interface has occurred.
CylinderCutoutResources_EN.xml	20043 An error occurred during an internal operation on an XML DOM or DOC object.
CylinderCutoutResources_EN.xml	20044 Failed to get data from helper.
CylinderCutoutResources_EN.xml	20045 Failed to cutout a cylinder.
CylinderCutoutResources_EN.xml	20046 Failed to set a cylinder to active.
CylinderCutoutResources_EN.xml	20047 Failed to check disabled cylinders.
CylinderCutoutResources_EN.xml	20048 Failed to suspend the test.
CylinderCutoutResources_EN.xml	20049 Failed to update cylinder cutout mode.
CylinderCutoutResources_EN.xml	20050 Test Aborted due to running condition failure.
CylinderCutoutResources_EN.xml	20051 Unable to initiate the test due to a precondition failure.
CylinderPerformance2Resources_EN.xml	16900 An internal error has occurred in the INSITE program.
CylinderPerformance2Resources_EN.xml	16904 An internal error has occurred in the test.
CylinderPerformance2Resources_EN.xml	16970 The test has failed to start due to precondition failure.
CylinderPerformance2Resources_EN.xml	16912 An error has occurred while attempting to print.
CylinderPerformance2Resources_EN.xml	16971 The test has been stopped on account of running precondition failure.
CylinderPerformance2Resources_EN.xml	20708 Error occurred in FlexGrid helper



CylinderPerformance2Resources_EN.xml	20709 Error occurred while dealing with User Interface element of feature window
CylinderPerformance2Resources_EN.xml	20710 There are insufficient resources to complete requested operation.
CylinderPerformanceGTIS45Resources_EN.xml	35400 INSITE failed to create required component.
CylinderPerformanceGTIS45Resources_EN.xml	35401 INSITE failed to stop Monitoring of parameters.
CylinderPerformanceGTIS45Resources_EN.xml	35402 INSITE failed to start Monitoring of parameters.
CylinderPerformanceGTIS45Resources_EN.xml	35403 INSITE failed to initialize Monitoring of parameters.
CylinderPerformanceGTIS45Resources_EN.xml	35404 An internal error has occurred in the INSITE program.
CylinderPerformanceGTIS45Resources_EN.xml	35405 INSITE failed to perform the requested ECM operation.
CylinderPerformanceGTIS45Resources_EN.xml	35406 Failed to acquire necessary kernel resources.
CylinderPerformanceGTIS45Resources_EN.xml	35407 Unable to start the Cylinder Performance Test.
CylinderPerformanceGTIS45Resources_EN.xml	35408 Failed to load a necessary resource.
CylinderPerformanceGTIS45Resources_EN.xml	35409 Failed to unsubscribe from necessary events.
CylinderPerformanceGTIS45Resources_EN.xml	35410 Failed to unpublish published events.
CylinderPerformanceGTIS45Resources_EN.xml	35411 Unable to properly stop the Cylinder Performance Test.
CylinderPerformanceGTIS45Resources_EN.xml	35412 Failed to subscribe to necessary events. Cylinder Performance Test may behave improperl
CylinderPerformanceGTIS45Resources_EN.xml	35413 Failed to publish necessary events.Cylinder Performance Test may behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	35414 Failed to the to initiate the Cylinder Performance Test may behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	Failed to the to read values of some parameters for the Cylinder Performance Test may
CylinderPerformanceGTIS45Resources_EN.xml	35415 behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	Failed to the to process the test status for the Cylinder Performance Test may behave
CylinderPerformanceGTIS45Resources_EN.xml	35416 improperly.
CylinderPerformanceGTIS45Resources_EN.xml	35417 INSITE failed to stop Monitoring of parameters.
CylinderPerformanceGTIS45Resources_EN.xml	Failed to the to read values of some parameters for the Cylinder Performance Test may
CylinderPerformanceGTIS45Resources_EN.xml	35418 behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	Failed to the to process the test changed status for engine speed for Cylinder Performance
CylinderPerformanceGTIS45Resources_EN.xml	35419 Test may behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	Failed to the to process the changed state of cylinder State for Cylinder Performance Test
CylinderPerformanceGTIS45Resources_EN.xml	35420 may behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	Failed to the to process the changed state of Bank for Cylinder Performance Test may
CylinderPerformanceGTIS45Resources_EN.xml	35421 behave improperly.
CylinderPerformanceGTIS45Resources_EN.xml	35422 Failed to enable the Cylinder Performance Test.
CylinderPerformanceGTIS45Resources_EN.xml	35423 Failed to enable the Cylinder Performance Test.
CylinderPerformanceGTIS45Resources_EN.xml	35424 Failed while the Cylinder Performance Test was unloaded .
CylinderPerformanceGTIS45Resources_EN.xml	35425 Failed to display Cylinder Performance Test value.
CylinderPerformanceGTIS45Resources_EN.xml	35426 Failed to update the status for Cylinder Performance Test .
CylinderPerformanceGTIS45Resources_EN.xml	35427 Failed to enable for Cylinder Performance Test .
CylinderPerformanceResources_EN.xml	16901 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16902 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16903 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16905 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16906 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16907 An internal error has occurred in the INSITE program.

CylinderPerformanceResources_EN.xml	16908 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16909 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16910 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16911 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16913 An error has occurred while attempting to print.
CylinderPerformanceResources_EN.xml	16914 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16915 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16916 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16917 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16918 Error occurred in FlexGrid helper
CylinderPerformanceResources_EN.xml CylinderPerformanceResources_EN.xml	16919 Error occurred while dealing with User Interface element of feature window
CylinderPerformanceResources_EN.xml	16920 There are insufficient resources to complete requested operation.
CylinderPerformanceResources_EN.xml	16950 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16951 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16952 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16953 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16954 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16955 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16956 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16957 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16958 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16959 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16960 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16961 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16962 An internal error has occurred in the INSITE program.
CylinderPerformanceResources_EN.xml	16963 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16964 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16965 An internal error has occurred in the test.

CylinderPerformanceResources_EN.xml	16966 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16967 An internal error has occurred in the test.
CylinderPerformanceResources_EN.xml	16968 Test stopped, no engine speed detected.
CylinderPerformanceResources_EN.xml	16969 Test stopped, vehicle speed detected.
CylinderPerformanceResources_EN.xml	16973 Test stopped, no RSC Sensor type detected.
DataMonitorLoggerResources_EN.xml	9000 An internal error occurred while updating the system on connection.
DataMonitorLoggerResources_EN.xml	9001 An internal error occurred while loading Data Monitor/Logger.
DataMonitorLoggerResources_EN.xml	9002 An internal error occurred while updating the system on disconnection.
DataMonitorLoggerResources_EN.xml	9003 Unknown error
DataMonitorLoggerResources_EN.xml	9004 No parameters were specified to add to the monitoring/logging session.
DataMonitorLoggerResources_EN.xml	9005 No parameters were specified to remove from the monitoring/logging session.
DataMonitorLoggerResources_EN.xml	9006 An error occurred while adding parameters to the monitoring/logging session.
DataMonitorLoggerResources_EN.xml	9007 An error occurred while removing parameters from the monitoring/logging session.
DataMonitorLoggerResources_EN.xml	9008 An error occurred while starting the monitoring/logging session.
DataMonitorLoggerResources_EN.xml	9009 An error occurred while stopping the monitoring/logging session.
DataMonitorLoggerResources_EN.xml	9010 An error occurred while starting the logger.
DataMonitorLoggerResources_EN.xml	9011 An error occurred while stopping the logger.
DutyCycleMonitorResources_EN.xml	18500 An internal error has occurred in the Duty Cycle Monitor.
DutyCycleMonitorResources_EN.xml	18501 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18502 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18503 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18504 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18505 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18506 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18507 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18508 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18509 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18510 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18511 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18512 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18513 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18514 An internal error has occurred in the INSITE Program.
DutyCycleMonitorResources_EN.xml	18515 Internal error while attempting to reset a Long Term Map.
DutyCycleMonitorResources_EN.xml	18516 Internal error while attempting to reset a Short Term Map.
DutyCycleMonitorResources_EN.xml	18517 Unable to reset the map. Non-zero engine speed has been detected.
DutyCycleMonitorResources_EN.xml	18310 An error has occurred.
DutyCycleMonitorResources_EN.xml	18311 A communication error has occurred.

DutyCycleMonitorResources_EN.xml	18312 Internal error while attempting to reset a Short Term Map.
DynamometerSetupGTIS45Resources_EN.xml	16000 An unidentified error occurred in the ECM Test Setup for Dynamometer Test.
DynamometerSetupGTIS45Resources_EN.xml	16001 An unidentified error occurred in the ECM Test Setup for Dynamometer Test
DynamometerSetupGTIS45Resources_EN.xml	16002 Failed to publish necessary events. Setup for Dynamometer may behave improperly
DynamometerSetupGTIS45Resources_EN.xml	16003 Failed to unpublish published events.
DynamometerSetupGTIS45Resources_EN.xml	16004 Failed to acquire necessary threading resources.
DynamometerSetupGTIS45Resources_EN.xml	16005 Failed to acquire necessary kernel resources.
DynamometerSetupGTIS45Resources_EN.xml	16006 Could not request the ECM to start test.
DynamometerSetupGTIS45Resources_EN.xml	16007 Could not request the ECM to stop test.
DynamometerSetupGTIS45Resources_EN.xml	16008 Unexpected error while posting internal advisories.
DynamometerSetupGTIS45Resources_EN.xml	16009 Failed to acquire a requested thread.
DynamometerSetupGTIS45Resources_EN.xml	16010 An error occurred during an internal operation on an XML DOM or DOC object.
DynamometerSetupGTIS45Resources_EN.xml	16011 Failed to post internal advisory.
DynamometerSetupGTIS45Resources_EN.xml	16012 Failure while requesting data from ECM Services.
DynamometerSetupGTIS45Resources_EN.xml	16013 The ECM Test Setup for Dynamometer Test has not been initialized.
DynamometerSetupGTIS45Resources_EN.xml	16014 Failed to initiate an operation to collect ECM data.
DynamometerSetupGTIS45Resources_EN.xml	16032 An unidentified error occurred in the ECM Test Setup for Dynamometer Test.
DynamometerSetupGTIS45Resources_EN.xml	16033 An unidentified error occurred in the ECM Test Setup for Dynamometer Test.
DynamometerSetupGTIS45Resources_EN.xml	16034 Failed to subscribe to necessary events. Setup for Dynamometer may behave improperly.
DynamometerSetupGTIS45Resources_EN.xml	16035 Failed to unsubscribe from necessary events.
DynamometerSetupGTIS45Resources_EN.xml	16036 Failed to acquire necessary Setup for Dynamometer.
DynamometerSetupGTIS45Resources_EN.xml	16037 Failed to start test.
DynamometerSetupGTIS45Resources_EN.xml	16038 Failed to stop possible test in progress.
DynamometerSetupGTIS45Resources_EN.xml	16039 Failed to stop possible test in progress while closing ECM Diagnostic Tests.
DynamometerSetupGTIS45Resources_EN.xml	16040 Failed to update Settings window. Displayed values may be invalid.
DynamometerSetupGTIS45Resources_EN.xml	16041 Unspecified error occurred while initializing test user interface.
DynamometerSetupGTIS45Resources_EN.xml	16042 Failed to load a necessary resource.
DynamometerSetupGTIS45Resources_EN.xml	16043 An Unspecified error occurred while initializing test user interface.
DynamometerSetupGTIS45Resources_EN.xml	16044 Unexpected failure of user interface has occurred.
DynamometerSetupGTIS45Resources_EN.xml	16045 An error occurred during an internal operation on an XML DOM or DOC object.
DynamometerSetupGTIS45Resources_EN.xml	16049 Failed to enable Test Throttle.
DynamometerSetupGTIS45Resources_EN.xml	16050 Failed to disable Test Throttle.
DynamometerSetupResources_EN.xml	16046 Failed to detect ESP Lock In Mode feature.
DynamometerSetupResources_EN.xml	16047 Failed to write ESP Lock In Mode Operational Curve value to ECM/Simulator.
DynamometerSetupResources_EN.xml	16048 Failed to read ESP Lock In Mode Operational Curve value from ECM/Simulator.
EGRValveResources_EN.xml	16700 An unexpected error occurred in the EGR Valve Test.
EGRValveResources_EN.xml	16701 An invalid delay was specified.
EGRValveResources_EN.xml	16702 An error occurred while attempting to create the thread.
EGRValveResources_EN.xml	16703 An error occurred while the page was unloading
EGRValveResources_EN.xml	16704 An error occurred while attempting to unsubscribe to mapped events
EGRValveResources_EN.xml	16705 An error occurred while attempting to unsubscribe to mapped events
EGRValveResources_EN.xml	16706 An error occurred while attempting to locate the Logic interface
EGRValveResources_EN.xml	16707 An error occurred while attempting to Initialize the page component
EGRValveResources_EN.xml	16708 An error occurred while attempting to Start the test
EGRValveResources_EN.xml	16709 An error occurred while attempting to Stop the test
EGRValveResources_EN.xml	16710 An error occurred while attempting to read a parameter
EGRValveResources_EN.xml	16711 An error occurred while attempting to write a parameter
EGRValveResources_EN.xml	16712 Test stopped, vehicle speed detected
EGRValveResources_EN.xml	16713 One or more of the PreConditions have failed
EGRValveResources_EN.xml	16714 An error occurred while attempting to open the EGR valve.
EGRValveResources_EN.xml	16715 An error occurred while attempting to close the EGR valve.
EGRValveResources_EN.xml	16716 An error occurred and the EGR valve could not be opened.
EGRValveResources_EN.xml	16717 An error occurred and the EGR valve could not be closed.
EGRValveResources_EN.xml	16718 An error occurred while attempting to start the ECMPoller.
EGRValveResources_EN.xml	16719 An error occurred while attempting to stop the ECMPoller.
EGRValveResources_EN.xml	16720 An error occurred while attempting to stop the test.
EGRValveResources_EN.xml	16721 Test stopped, EGR valve position sensor circuit fault detected.
EGRValveResources_EN.xml	16722 Test stopped, EGR valve position sensor circuit fault detected.
EGRValveResources_EN.xml	16723 Test stopped. Turbocharger control valve circuit fault code indicates an error.
EGRValveResources_EN.xml	16724 Test stopped. An error is detected in the ECM.
EGRVGTOperationalResources_EN.xml	16600 An unknown error occurred.
EGRVGTOperationalResources_EN.xml	16601 An error occurred while loading the title of this test.

EGRVGTOperationalResources_EN.xml	16602 An error occurred while loading the subtitle of this test.
EGRVGTOperationalResources_EN.xml	16603 Unable to start the EGR/VGT Operational Test.
EGRVGTOperationalResources_EN.xml	16604 Base class initialization failed.
EGRVGTOperationalResources_EN.xml	16605 Could not Query logic.
EGRVGTOperationalResources_EN.xml	16606 Could not register as publisher.
EGRVGTOperationalResources_EN.xml	16607 Could not register as subscriber.
EGRVGTOperationalResources_EN.xml	16608 The UI has entered an invalid state.
EGRVGTOperationalResources_EN.xml	16609 Could not unpublish test events.
EGRVGTOperationalResources_EN.xml	16610 Could not unsubscribe from receiving system messages.
EGRVGTOperationalResources_EN.xml	16611 Logic returned an invalid status message.
EGRVGTOperationalResources_EN.xml	16612 Logic reported an error condition.
EGRVGTOperationalResources_EN.xml	16613 Logic could not properly fire a thread.
EGRVGTOperationalResources_EN.xml	16614 Logic could not query the thread service.
EGRVGTOperationalResources_EN.xml	16616 Could not query the reason for the stop condition.
EGRVGTOperationalResources_EN.xml	16617 Could not correctly close the EGR Valve. Aborting test.
EGRVGTOperationalResources_EN.xml	16618 Could not correctly open the VGT Actuator. Aborting test.
EGRVGTOperationalResources_EN.xml	16619 Invalid pointer passed into ECMRead. Aborting read.
EGRVGTOperationalResources_EN.xml	16620 ECMRead could not complete ReadNode call. Aborting read.
EGRVGTOperationalResources_EN.xml	16621 ECMWrite could not complete CommitNode call. Aborting write.
EGRVGTOperationalResources_EN.xml	16622 An error occurred while setting up the test. Aborting test.
EGRVGTOperationalResources_EN.xml	16623 Could not correctly open the EGR Valve. Aborting test.
EGRVGTOperationalResources_EN.xml	16624 Could not correctly close the VGT Actuator. Aborting test.
EGRVGTOperationalResources_EN.xml	16625 The EGR Valve position sensor indicates the valve is not fully closed. The Turbocharger test will not run unless the EGR valve is fully closed.
EGRVGTOperationalResources_EN.xml	16626 A critical failure occurred while stopping the test.
EngineAbuseHistoryResources_EN.xml	21300 An error occurred with Engine Abuse History.
EngineAbuseHistoryResources_EN.xml	21301 An error occurred with Engine Abuse History.
EngineAbuseHistoryResources_EN.xml	21302 An error occurred with Engine Abuse History.
EngineProtectionResources_EN.xml	18100 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18102 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18103 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18104 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18101 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18105 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18106 INSITE has detected an error in the Engine Protection feature.

EngineProtectionResources_EN.xml	18107 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18108 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18150 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18151 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18152 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18153 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18154 INSITE has detected an error in the Engine Protection feature.
EngineProtectionResources_EN.xml	18155 An internal error has occurred in the INSITE Program.
EngineProtectionResources_EN.xml	18156 An internal error has occurred in the INSITE Program.
EngineProtectionResources_EN.xml	18158 No engine protection data is available to be printed.
EngineProtectionResources_EN.xml	18157 An unknown error occurred while printing engine protection data.
EngineProtectionResources_EN.xml	18159 An internal error has occurred in the INSITE Program.
EngineProtectionResources_EN.xml	18160 An internal error has occurred in the INSITE Program.
EngineProtectionResources_EN.xml	18161 An internal error has occurred in the INSITE Program.
EngineProtectionResources_EN.xml	18109 An internal error has occurred in the INSITE Program.
EngineProtectionResources_EN.xml	18110 An internal error has occurred in the INSITE Program.
EngineStateMonitorResources_EN.xml	40061 The test status parameter has returned a value of "nnn". This value is outside of the expected range
EPWTestResources_EN.xml	17620 INSITE failed to perform the requested ECM operation.
EPWTestResources_EN.xml	17602 An unidentified error occurred in the ECM Test "Engine Protection Witness Test".
EngineTorqueHistoryGTIS45Resources_EN.xml	2001 Error in reading the feature enable token.
EngineTorqueHistoryGTIS45Resources_EN.xml	2002 Error in reading fault status token.
EngineTorqueHistoryGTIS45Resources_EN.xml	2003 Error in reading the token.
EngineTorqueHistoryGTIS45Resources_EN.xml	2004 Error in reading the safe array.
EngineTorqueHistoryGTIS45Resources_EN.xml	2005 Error in publishing the event.
EngineTorqueHistoryGTIS45Resources_EN.xml	2501 Error in loading ECM property page helper class.
EngineTorqueHistoryGTIS45Resources_EN.xml	2502 Error in unloading ECM property page helper class.
EngineTorqueHistoryGTIS45Resources_EN.xml	2006 Failed to find logic events
EngineTorqueHistoryGTIS45Resources_EN.xml	2007 Failed to unregister the publisher.
EngineTorqueHistoryGTIS45Resources_EN.xml	2008 Error in getting log.
EngineTorqueHistoryGTIS45Resources_EN.xml	2503 Error in some FlexGrid operation.

EngineTorqueHistoryGTIS45Resources_EN.xml	2009 Error in getting record info.
EngineTorqueHistoryGTIS45Resources_EN.xml	2010 Error in accessing data from safearray.
EngineTorqueHistoryGTIS45Resources_EN.xml	2011 Error in unaccessing data from safearray.
EngineTorqueHistoryGTIS45Resources_EN.xml	2504 Error in accessing data from safearray.
EngineTorqueHistoryGTIS45Resources_EN.xml	2505 Error in unaccessing data from safearray.
EngineTorqueResources_EN.xml	18001 An unexpected error occurred.
EngineTorqueResources_EN.xml	18002 Engine Torque initialization failed.
EngineTorqueResources_EN.xml	18003 Engine Torque failed to subscribe to mapped events.
EngineTorqueResources_EN.xml	18004 Engine Torque encountered a NULL pointer.
EngineTorqueResources_EN.xml	18005 Engine Torque failed to query for a required interface.
EngineTorqueResources_EN.xml	18006 Engine Torque failed to unsubscribe from mapped events.
EngineTorqueResources_EN.xml	18007 Engine Torque failed to unload successfully.
EngineTorqueResources_EN.xml	18008 Engine Torque failed to advise the flexgrid sink map.
EngineTorqueResources_EN.xml	18009 Engine Torque failed to load the context menu.
EngineTorqueResources_EN.xml	18010 Engine Torque failed to load a submenu.
EngineTorqueResources_EN.xml	18011 Engine Torque failed to find a dialog item.
EngineTorqueResources_EN.xml	18012 Engine Torque failed to query for a control.
EngineTorqueResources_EN.xml	18013 Engine Torque failed to find a required registry key.
EngineTorqueResources_EN.xml	18014 Engine Torque failed to perform a grid redraw.
EngineTorqueResources_EN.xml	18015 Engine Torque failed to get or set the background color.
EngineTorqueResources_EN.xml	18016 Engine Torque failed to get or set the background color.
EngineTorqueResources_EN.xml	18017 Engine Torque failed to get or set the alternate background color.
EngineTorqueResources_EN.xml	18018 Engine Torque failed to get or set the grid sheet border color.
EngineTorqueResources_EN.xml	18019 Engine Torque failed to get or set the grid fixed background color.
EngineTorqueResources_EN.xml	18020 Engine Torque failed to get or set the grid font italic property.
EngineTorqueResources_EN.xml	18021 Engine Torque failed to get or set the grid font name.
EngineTorqueResources_EN.xml	18022 Engine Torque failed to get or set the grid font size.
EngineTorqueResources_EN.xml	18023 Engine Torque failed to get or set the grid font strikethru property.
EngineTorqueResources_EN.xml	18024 Engine Torque failed to get or set the grid font underline property.
EngineTorqueResources_EN.xml	18025 Engine Torque failed to get or set the grid forecolor property.
EngineTorqueResources_EN.xml	18026 Engine Torque failed to get or set the grid mouse pointer.
EngineTorqueResources_EN.xml	18027 Engine Torque failed to CoCreateInstance an object.
EngineTorqueResources_EN.xml	18028 Engine Torque failed to create an element.
EngineTorqueResources_EN.xml	18029 Engine Torque failed to clear the grid.
EngineTorqueResources_EN.xml	18030 Engine Torque failed to get or set the grid rows.
EngineTorqueResources_EN.xml	18031 Engine Torque failed to get or set the grid xml property.
EngineTorqueResources_EN.xml	18032 Engine Torque failed to reset a node list.
EngineTorqueResources_EN.xml	18033 Engine Torque failed to get a node name.
EngineTorqueResources_EN.xml	18034 Engine Torque failed to get a child node.
EngineTorqueResources_EN.xml	18035 Engine Torque failed to get a next node.
EngineTorqueResources_EN.xml	18036 Engine Torque failed to get a value from a node.
EngineTorqueResources_EN.xml	18037 Engine Torque failed to add an entry to the grid.
EngineTorqueResources_EN.xml	18038 Engine Torque failed to append a child to a node.
EngineTorqueResources_EN.xml	18039 Engine Torque failed to extend the last column.
EngineTorqueResources_EN.xml	18040 Engine Torque failed to get or set the grid outline property.
EngineTorqueResources_EN.xml	18041 Engine Torque failed to get or set the grid autosize property.
EngineTorqueResources_EN.xml	18042 Engine Torque failed to get or set the grid row property.
EngineTorqueResources_EN.xml	18043 Engine Torque failed to add an item to the grid.
EngineTorqueResources_EN.xml	18044 Engine Torque failed to set an attribute on a node.
EngineTorqueResources_EN.xml	18045 Engine Torque failed to get or set the grid Subtotal property.
EngineTorqueResources_EN.xml	18046 Engine Torque failed to get or set the grid RowOutlineLevel property.
EngineTorqueResources_EN.xml	18047 Engine Torque failed to get or set the grid Cell property.
EngineTorqueResources_EN.xml	18048 Engine Torque failed to select a single node from a node list.
EngineTorqueResources_EN.xml	18049 Engine Torque failed to attach to a node.
EngineTorqueResources_EN.xml	18050 Engine Torque failed to detach from a node.
EngineTorqueResources_EN.xml	18051 Engine Torque failed to get engine torque data from the worker.
EngineTorqueResources_EN.xml	18052 Engine Torque failed to get or set the grid cols property.
EngineTorqueResources_EN.xml	18053 Engine Torque failed to get or set the grid AllowUserResizing property.
EngineTorqueResources_EN.xml	18054 Engine Torque failed to get or set the grid AutoSearch property.
EngineTorqueResources_EN.xml	18055 Engine Torque failed to get or set the grid GridLines property.
EngineTorqueResources_EN.xml	18056 Engine Torque failed to get or set the grid OutlineBar property.
EngineTorqueResources_EN.xml	18057 Engine Torque failed to get or set the grid AllowSelection property.
EngineTorqueResources_EN.xml	18058 Engine Torque failed to load a string from the string table.
EngineTorqueResources_EN.xml	18059 Engine Torque failed to get or set the grid BottomRow property.
EngineTorqueResources_EN.xml	18060 Engine Torque failed to get or set the grid FixedCols property.
EngineTorqueResources_EN.xml	18061 Engine Torque failed to get or set the grid AllowBigSelection property.
EngineTorqueResources_EN.xml	18062 Engine Torque failed to get or set the grid BorderStyle property.
EngineTorqueResources_EN.xml	18063 Engine Torque failed to get or set the grid FixedRows property.
EngineTorqueResources_EN.xml	18064 Engine Torque failed to get or set the grid OutlineCol property.
EngineTorqueResources_EN.xml	18065 Engine Torque failed to get or set the grid ScrollBars property.
EngineTorqueResources_EN.xml	18066 Engine Torque failed to get or set the grid AllowUserResizing property.

EngineTorqueResources_EN.xml	18067 Engine Torque failed to get or set the grid ColAlignment property.
EngineTorqueResources_EN.xml	18068 Engine Torque failed to get or set the grid SelectionMode property.
EngineTorqueResources_EN.xml	18069 Engine Torque failed to get or set the grid AllowSelection property.
EngineTorqueResources_EN.xml	18070 Engine Torque failed to get or set the grid HighLight property.
EngineTorqueResources_EN.xml	18071 Engine Torque failed to get or set the grid TextMatrix property.
EngineTorqueResources_EN.xml	18072 Engine Torque failed to get or set the grid IsCollapsed property.
EngineTorqueResources_EN.xml	18073 Engine Torque failed to get or set the grid GetNode property.
EngineTorqueResources_EN.xml	18074 Engine Torque failed to get children from a node.
EngineTorqueResources_EN.xml	18075 Engine Torque failed to get or set the grid GetNodeRow property.
EngineTorqueResources_EN.xml	18076 Engine Torque failed to destroy a menu.
EngineTorqueResources_EN.xml	18077 Engine Torque failed to get or set the grid MouseCol property.
EngineTorqueResources_EN.xml	18078 Engine Torque failed to get or set the grid MouseRow property.
EngineTorqueResources_EN.xml	18079 Engine Torque failed to get or set the grid Select property.
EngineTorqueResources_EN.xml	18080 Engine Torque failed to load a style sheet.
EngineTorqueResources_EN.xml	18081 Engine Torque failed to query for the print interface.
EngineTorqueResources_EN.xml	18082 Engine Torque failed to display the print dialog.
EngineTorqueResources_EN.xml	18083 Engine Torque failed to release the print interface.
EngineTorqueResources_EN.xml	18084 Engine Torque failed to load data into a style sheet.
EngineTorqueResources_EN.xml	18085 Engine Torque failed to setup grid options.
EngineTorqueResources_EN.xml	18201 An unexpected error occurred.
EngineTorqueResources_EN.xml	18202 Engine Torque Worker failed to publish mapped events.
EngineTorqueResources_EN.xml	18203 Engine Torque Worker failed to subscribe to mapped events.
EngineTorqueResources_EN.xml	18204 Engine Torque Worker encountered a NULL pointer.
EngineTorqueResources_EN.xml	18205 Engine Torque Worker failed to unsubscribe to mapped events.
EngineTorqueResources_EN.xml	18206 Engine Torque Worker failed to unregister as an event publisher.
EngineTorqueResources_EN.xml	18207 Engine Torque Worker failed to unload successfully.
EngineTorqueResources_EN.xml	18208 Engine Torque Worker failed to create a child element.
EngineTorqueResources_EN.xml	18209 Engine Torque Worker failed to call and Invoke method.
EngineTorqueResources_EN.xml	18210 Engine Torque Worker failed to CoCreateInstance an XML DOM.
EngineTorqueResources_EN.xml	18211 Engine Torque Worker failed to create a node.
EngineTorqueResources_EN.xml	18212 Engine Torque Worker failed to append a child to a node.
EngineTorqueResources_EN.xml	18213 Engine Torque Worker failed to read a node.
EngineTorqueResources_EN.xml	18214 Engine Torque Worker failed to get a value from a node.
EngineTorqueResources_EN.xml	18215 Engine Torque Worker failed to create a group.
EngineTorqueResources_EN.xml	18216 Engine Torque Worker failed to clone a node.
EngineTorqueResources_EN.xml	18217 Engine Torque Worker failed to get xml.
EngineTorqueResources_EN.xml	40008 An internal error has occurred in the Engine Torque.
EngineTorqueResources_EN.xml	40009 An internal error has occurred in the Engine Torque.
EtherInjectionResetGTIS45SPResources_EN.xml	17500 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17510 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17511 INSITE was unable to determine if the test is available on this ECM.
EtherInjectionResetGTIS45SPResources_EN.xml	17512 The test is not supported by the current calibration.
EtherInjectionResetGTIS45SPResources_EN.xml	17513 INSITE failed to perform the requested ECM operation.
EtherInjectionResetGTIS45SPResources_EN.xml	17514 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17515 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17516 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17517 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17518 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17519 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17520 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17521 INSITE failed to perform the requested ECM operation.
EtherInjectionResetGTIS45SPResources_EN.xml	17522 INSITE failed to perform the requested ECM operation.
EtherInjectionResetGTIS45SPResources_EN.xml	17523 An internal error has occurred in the INSITE program.



EtherInjectionResetGTIS45SPResources_EN.xml	17524 INSITE has detected the PC is running low on system resources.
EtherInjectionResetGTIS45SPResources_EN.xml	17525 An internal error has occurred in the INSITE program.
EtherInjectionResetGTIS45SPResources_EN.xml	17526 An internal error has occurred in the INSITE program.
EtherInjectionResetGTIS45SPResources_EN.xml	17527 An internal error has occurred in the INSITE program.
EtherInjectionResetGTIS45SPResources_EN.xml	17528 Failed to determine whether test is enabled in the ECM The ECM detects a condition in which the Ether Injection Reset cannot be ran. Please select Help for further detail.
EtherInjectionResetGTIS45SPResources_EN.xml	17529 ECM Response Code: XXX
EtherInjectionResetGTIS45SPResources_EN.xml	17530 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17531 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	17532 Failed to find logic events.
EtherInjectionResetGTIS45SPResources_EN.xml	17533 Failed to get monitor id.
EtherInjectionResetGTIS45SPResources_EN.xml	17534 Failed to get monitors pointer.
EtherInjectionResetGTIS45SPResources_EN.xml	17535 Failed to get monitor service.
EtherInjectionResetGTIS45SPResources_EN.xml	17536 Failed to subscribe events.
EtherInjectionResetGTIS45SPResources_EN.xml	17537 Failed to unsubscribe events.
EtherInjectionResetGTIS45SPResources_EN.xml	17538 Failed to get connection point server.
EtherInjectionResetGTIS45SPResources_EN.xml	17539 Failed to add module to monitor service.
EtherInjectionResetGTIS45SPResources_EN.xml	17540 Failed to add parameter to monitor.
EtherInjectionResetGTIS45SPResources_EN.xml	17541 An unidentified error occurred in the ECM Test "EtherInjectionReset Test".
EtherInjectionResetGTIS45SPResources_EN.xml	28707 INSITE failed to get schema file path.
EtherInjectionResetGTIS45SPResources_EN.xml	28701 Error occurred while initializing dialog.
FanOverrideGTISResources_EN.xml	16500 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16501 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16502 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16503 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16504 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16505 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16506 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16507 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16508 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16509 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16510 INSITE was unable to determine if the test is available on this ECM.
FanOverrideGTISResources_EN.xml	16511 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16512 An internal error has occurred in the INSITE program.

FanOverrideGTISResources_EN.xml	16513 INSITE failed to perform the requested ECM operation.
FanOverrideGTISResources_EN.xml	16514 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16515 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16516 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16517 INSITE failed to perform the requested ECM operation.
FanOverrideGTISResources_EN.xml	16518 The engine must be running to perform this test.
FanOverrideGTISResources_EN.xml	16519 The test is not supported by the current calibration.
FanOverrideGTISResources_EN.xml	16550 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16551 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16552 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16553 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16554 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16555 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16556 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16557 INSITE failed to perform the requested ECM operation.
FanOverrideGTISResources_EN.xml	16558 INSITE failed to perform the requested ECM operation.
FanOverrideGTISResources_EN.xml	16559 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16560 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16561 INSITE was unable to determine if the test is available on this ECM.
FanOverrideGTISResources_EN.xml	16562 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16563 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16564 INSITE has detected the PC is running low on system resources.
FanOverrideGTISResources_EN.xml	16565 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16566 An internal error has occurred in the INSITE program.
FanOverrideGTISResources_EN.xml	16567 An internal error has occurred in the INSITE program.
FastIdleWarmupGTIS45Resources_EN.xml	16015 Internal error while setting up the data for printing.
FastIdleWarmupGTIS45Resources_EN.xml	16051 Failed to get Execution time.
FaultsInformationResources_EN.xml	7000 A pointer evaluated to NULL.
FaultsInformationResources_EN.xml	7001 A call to CoCreateInstance failed.
FaultsInformationResources_EN.xml	7003 A call using a XMLDOMDocument failed.
FaultsInformationResources_EN.xml	7004 A call using a XMLDOMNode failed.
FaultsInformationResources_EN.xml	7005 A call using NodeBuddy failed.
FaultsInformationResources_EN.xml	7006 A CLSID conversion function failed.

FaultsInformationResources_EN.xml	7007 You cannot use print functionality when no ECM is connected.
FaultsInformationResources_EN.xml	7008 An attempt to read a value from the registry failed.
FaultsInformationResources_EN.xml	7009 A call to DisplayFaults failed.
FaultsInformationResources_EN.xml	7010 A call to QueryInterface failed.
FaultsInformationResources_EN.xml	7012 The request to reset inactive faults failed.
FaultsInformationResources_EN.xml	7013 A call to getXML failed.
FaultsInformationResources_EN.xml	7014 A call to a thread function failed.
FaultsInformationResources_EN.xml	7015 A call to ReadSnapshot failed.
FaultsInformationResources_EN.xml	7016 A call to ECMDDataServices failed.
FaultsInformationResources_EN.xml	7026 A call to ECMDDataGroup failed.
FaultsInformationResources_EN.xml	7017 A security check failed.
FaultsInformationResources_EN.xml	7018 A call to LoadString failed.
FaultsInformationResources_EN.xml	7019 An internal application error occurred. The grid control did not initialize.
FaultsInformationResources_EN.xml	7020 Error setting up grid control default layout.
FaultsInformationResources_EN.xml	This action cannot be completed at this time. The ECM is currently locked by another activi
FaultsInformationResources_EN.xml	7021 in progress and is not available.
FaultsInformationResources_EN.xml	7022 The snapshot data requested is invalid.
	7023 Fault tree information is not available for the current ECM.
FaultsInformationResources_EN.xml	7024 An attempt to reset inactive faults failed because the Engine Speed is not equal to zero.
FaultsInformationResources_EN.xml	7025 An attempt to RefreshFaults failed.
FaultsInformationResources_EN.xml	7028 The connected ECM type is not supported by the installed faults resource file.
FaultsInformationResources_EN.xml	7029 The request to reset all faults failed.
FeaturesAndParametersResources_EN.xml	8500 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8501 An internal error has occurred in the INSITE program while reading Trip Information.
FeaturesAndParametersResources_EN.xml	An internal error has occurred in the INSITE program while attempting to reset Trip
	8502 Information.
FeaturesAndParametersResources_EN.xml	8503 An internal error has occurred in the INSITE program with Page Setup.
FeaturesAndParametersResources_EN.xml	8504 An internal error has occurred in the INSITE program with Print Preview.
FeaturesAndParametersResources_EN.xml	8505 An Internal error has occurred in the INSITE program while Printing.
FeaturesAndParametersResources_EN.xml	8506 An internal error has occurred in the INSITE program while Printing.
FeaturesAndParametersResources_EN.xml	An internal error has occurred in the INSITE program while attempting to display trip
	8507 information.
FeaturesAndParametersResources_EN.xml	8508 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	INSITE has detected the PC is running low on system resources and cannot display Trip
	8509 Information.
FeaturesAndParametersResources_EN.xml	8510 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8511 An internal error has occurred in the INSITE program.

FeaturesAndParametersResources_EN.xml	8512 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8513 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8514 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8515 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8516 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8517 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8518 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8519 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8520 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8521 An error occurred while attempting to perform a Trip Information search.
FeaturesAndParametersResources_EN.xml	8522 Trip Information Search function has encountered an internal error.
FeaturesAndParametersResources_EN.xml	8530 An internal error has occurred in the INSITE program while attempting to display Trip Information.
FeaturesAndParametersResources_EN.xml	8531 INSITE has detected the PC is running low on system resources and cannot display Trip Information.
FeaturesAndParametersResources_EN.xml	8527 INSITE has detected the PC is running low on system resources and cannot display Trip Information.
FeaturesAndParametersResources_EN.xml	8532 An internal error has occurred in the INSITE program while attempting to enable or disable Trip Information user interface.
FeaturesAndParametersResources_EN.xml	8525 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8528 INSITE has detected the PC is running low on system resources and cannot display Trip Information.
FeaturesAndParametersResources_EN.xml	8523 An internal error has occurred in the INSITE program while searching for the specified item Trip Information.
FeaturesAndParametersResources_EN.xml	8529 An internal error has occurred in the INSITE program.
FeaturesAndParametersResources_EN.xml	8526 INSITE has detected the PC is running low on system resources and cannot display Trip Information.

FeaturesAndParametersResources_EN.xml	An internal error has occurred in the INSITE program while selecting and displaying the 8524 specified item in Trip Information.
FuelConsumptionMonitorResources_EN.xml	28702 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28703 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28704 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28705 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28706 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28708 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28709 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28710 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	An internal error has occurred in the updateParameterData method of Fuel Consumption Monitor page class. 28711
FuelConsumptionMonitorResources_EN.xml	28850 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28851 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28852 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28853 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28854 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28855 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28856 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	28857 An internal error has occurred in the Fuel Consumption Monitor.
FuelConsumptionMonitorResources_EN.xml	There has been an error while reading the Fuel Consumption Monitor Data. Please select H 28858 for more information.
FuelConsumptionMonitorResources_EN.xml	The ECM detects a condition in which the Fuel Consumption Monitor cannot be reset. Please select Help for further detail. 28859 ECM Response Code: X
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17650 An Internal Error has occurred in INSITE Program.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17651 An Internal Error has occurred in INSITE Program.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17652 An error occurred while getting the thread facility.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17653 An error occurred while requesting a new thread.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17654 An error occurred while starting the test.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17655 An error occurred while publishing events.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17656 An error occurred while un-publishing events.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17657 INSITE failed to perform the requested ECM operation.

FuelLiftPumpOverrideGTIS45Resources_EN.xml	17658 Unable to read test token.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17659 Unable to write to test token.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17660 Failed to find logic events.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17661 Failed to get the pointer to monitors.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17662 Failed to get the monitor id.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17663 Failed to get the monitor service.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17664 Failed to get the connection point server.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17665 Failed to add module to monitors.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17666 Failed to add parameter to monitors.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17667 Failed to subscribe events.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17668 Failed to unsubscribe events.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17669 An error occurred while invoking advise.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17670 An error occurred while invoking unadvise.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17671 An error occurred while stopping the monitors.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17672 An error occurred while adjusting electric fuel lift pump position.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17673 INSITE has detected the PC is running low on system resources.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17674 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17675 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17676 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17677 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17678 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17679 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17680 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17681 INSITE failed to perform the requested ECM operation.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17682 INSITE failed to perform the requested ECM operation.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17683 An internal error has occurred in the INSITE program.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17684 INSITE has detected the PC is running low on system resources.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17685 An internal error has occurred in the INSITE program.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17686 An internal error has occurred in the INSITE program.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17687 An internal error has occurred in the INSITE program.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17688 Failed to determine whether test is enabled in the ECM.
FuelLiftPumpOverrideGTIS45Resources_EN.xml	17689 An unidentified error occurred in the ECM Test "Electric Fuel Lift Pump Override Test".
FuelPumpTest Resources_EN.xml	40010 An unidentified error occurred in the ECM Test "Fuel Pump Test".

FuelPumpTest Resources_EN.xml	40011 An unidentified error occurred in the ECM Test "Fuel Pump Test".
FuelPumpTest Resources_EN.xml	40012 Failed to publish events.
FuelPumpTest Resources_EN.xml	40013 Failed to unublish events.
FuelPumpTest Resources_EN.xml	40014 Failed to initialize the ECM.
FuelPumpTest Resources_EN.xml	40015 An unidentified error occurred in starting the test.
FuelPumpTest Resources_EN.xml	40016 An unidentified error occurred in stopping the test.
FuelPumpTest Resources_EN.xml	40017 INSITE was unable to determine if the test is available on this ECM.
FuelPumpTest Resources_EN.xml	40018 INSITE failed to perform to perform ECM operation.
FuelPumpTest Resources_EN.xml	40019 The test is not supported by the current calibration.
FuelPumpTest Resources_EN.xml	40020 Failed to read Test token.
FuelPumpTest Resources_EN.xml	40021 Failed to write Test token.
FuelPumpTest Resources_EN.xml	40022 Failed to find logic events.
FuelPumpTest Resources_EN.xml	40023 Failed to get monitors pointer.
FuelPumpTest Resources_EN.xml	40024 Failed to get monitor ID.
FuelPumpTest Resources_EN.xml	40025 Failed to get monitor service.
FuelPumpTest Resources_EN.xml	40026 Failed to get connection point server.
FuelPumpTest Resources_EN.xml	40027 Failed to add modules to monitor.
FuelPumpTest Resources_EN.xml	40028 Failed to subscribe the event.
FuelPumpTest Resources_EN.xml	40029 Failed to unsubscribe the event.
FuelPumpTest Resources_EN.xml	40030 An unidentified error occurred in invoking Advise.
FuelPumpTest Resources_EN.xml	40031 An unidentified error occurred in invoking Unadvise.
FuelPumpTest Resources_EN.xml	40032 An unidentified error occurred in stopping the monitor.
FuelPumpTest Resources_EN.xml	40033 Out of memory.
FuelPumpTest Resources_EN.xml	40034 Error in firing a message.
FuelPumpTest Resources_EN.xml	40035 Error in starting the monitor.
FuelPumpTest Resources_EN.xml	40036 Error in stopping the monitor.
FuelPumpTest Resources_EN.xml	40037 Error in reading a token.
FuelPumpTest Resources_EN.xml	40038 Error in writing a token.
FuelPumpTest Resources_EN.xml	40039 Failed in unload of base in Logic.
FuelPumpTest Resources_EN.xml	40040 An unidentified error occurred in the ECM Test "Fuel Pump Test".
FuelPumpTest Resources_EN.xml	40041 An unidentified error occurred in the ECM Test "Fuel Pump Test".
FuelPumpTest Resources_EN.xml	40042 Failed to subscribe to necessary events. Fuel Pump Test may behave improperly.
FuelPumpTest Resources_EN.xml	40043 Failed to unsubscribe events in page.
FuelPumpTest Resources_EN.xml	40044 Failed to publish necessary events. Fuel Pump Test may behave improperly.
FuelPumpTest Resources_EN.xml	40045 Failed to unublish published events.
FuelPumpTest Resources_EN.xml	40046 Failed in unload of base in Page.
FuelPumpTest Resources_EN.xml	40047 INSITE failed to Start the Test.
FuelPumpTest Resources_EN.xml	40048 INSITE failed to Stop the Test.
FuelPumpTest Resources_EN.xml	40049 Failed to initialize User Interface Objects.

FuelPumpTest Resources_EN.xml	40050 Failed to stop possible test in progress while closing ECM Diagnostic Tests.
FuelPumpTest Resources_EN.xml	40051 The test is not supported by the current calibration.
FuelPumpTest Resources_EN.xml	40052 INSITE has detected the PC is running low on system resources.
FuelPumpTest Resources_EN.xml	40053 An unidentified error occurred in the ECM Test "Fuel Pump Test".
AHNOxResetTestGTIS45Resources_xx.xml	40202 "The test cannot run due to critical parameters being unavailable."
FuelSystemLeakageGTIS45Resources_EN.xml	20100 An unknown error occurred within the Fuel System Leakage Test Page.
FuelSystemLeakageGTIS45Resources_EN.xml	20101 The test was aborted because the Vehicle Speed is greater than 0.
FuelSystemLeakageGTIS45Resources_EN.xml	20102 The test was aborted because the Engine Speed exceeded the test limit.
FuelSystemLeakageGTIS45Resources_EN.xml	20103 The test was aborted due to a Fuel Rail Pressure exceeding the maximum threshold.
FuelSystemLeakageGTIS45Resources_EN.xml	20104 Base class initialization failed.
FuelSystemLeakageGTIS45Resources_EN.xml	20105 Could not Query logic.
FuelSystemLeakageGTIS45Resources_EN.xml	20107 Could not register as publisher.
FuelSystemLeakageGTIS45Resources_EN.xml	20108 Could not register as subscriber.
FuelSystemLeakageGTIS45Resources_EN.xml	20109 Could not unpublish test events.
FuelSystemLeakageGTIS45Resources_EN.xml	20110 Could not unsubscribe from receiving system messages.
FuelSystemLeakageGTIS45Resources_EN.xml	20111 Unable to start the Fuel System Leakage Test.
FuelSystemLeakageGTIS45Resources_EN.xml	20112 Unable to properly stop the Fuel System Leakage Test.
FuelSystemLeakageGTIS45Resources_EN.xml	20113 An error occurred while loading a string for the page.
FuelSystemLeakageGTIS45Resources_EN.xml	20114 The test has been aborted for an unknown reason.
FuelSystemLeakageGTIS45Resources_EN.xml	20115 The test was not started because no Engine Speed was detected.
FuelSystemLeakageGTIS45Resources_EN.xml	20116 The test was not started because the Vehicle Speed was greater than 0.
FuelSystemLeakageGTIS45Resources_EN.xml	20117 The test was not started because the Engine Speed exceeded the test limit.
FuelSystemLeakageGTIS45Resources_EN.xml	20118 The test was not started due to the Fuel Rail Pressure failing to meet the minimum threshold
FuelSystemLeakageGTIS45Resources_EN.xml	20119 ECM calibration does not support this test.
FuelSystemLeakageGTIS45Resources_EN.xml	20120 The test was not started because 1139 or 1141 or 1142 or 1143 or 1144 or 1145 or 1146 is active.
FuelSystemLeakageGTIS45Resources_EN.xml	20121 The test was aborted because the Engine Speed was less than 600 RPM.
FuelSystemTableResetGTIS45Resources_EN.xml	35701 An Internal Error has occurred in INSITE Program.
FuelSystemTableResetGTIS45Resources_EN.xml	35702 Error during initializing the logic.
FuelSystemTableResetGTIS45Resources_EN.xml	35703 Error during unload of the logic.
FuelSystemTableResetGTIS45Resources_EN.xml	35704 Failed to read the feature enable token.
FuelSystemTableResetGTIS45Resources_EN.xml	35705 Error occurred while reading a token from ECM.
FuelSystemTableResetGTIS45Resources_EN.xml	35706 Error occurred while writing a token to ECM.
FuelSystemTableResetGTIS45Resources_EN.xml	35707 Error occurred while resetting the fuel system table .
FuelSystemTableResetGTIS45Resources_EN.xml	35751 An Internal Error has occurred in INSITE Program.
FuelSystemTableResetGTIS45Resources_EN.xml	35752 An Internal Error has occurred in INSITE Program during feature page initialization.



FuelSystemTableResetGTIS45Resources_EN.xml	35753 An internal error occurred during unloading of the Fuel System Table Reset special feature
FuelSystemTableResetGTIS45Resources_EN.xml	35754 INSITE was unable to determine if the feature is supported by the application
FuelSystemTableResetGTIS45Resources_EN.xml	35755 Error occurred while reading a parameter.
FuelSystemTableResetGTIS45Resources_EN.xml	35756 Error occurred while writing a parameter
FuelSystemTableResetGTIS45Resources_EN.xml	35757 Error occurred while resetting the fuel system tables.
FuelSystemTableResetResources_EN.xml	16300 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16301 System memory is low.
FuelSystemTableResetResources_EN.xml	16302 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16320 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16321 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16360 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16361 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16362 Engine speed is greater than zero rpm.
FuelSystemTableResetResources_EN.xml	16363 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16364 The reset cannot be completed.
FuelSystemTableResetResources_EN.xml	16303 An error occurred in the ECM Fuel System Table Reset test.
FuelSystemTableResetResources_EN.xml	16324 An error occurred in the ECM Fuel System Table Reset test.
HeatedOxygenSensorTestResources_EN.xml	20106 Could not register as subscriber.
HeatedOxygenSensorTestResources_EN.xml	201091 Unable to start the Heated Oxygen Sensor Test.
InquireDataExtractionResources_EN.xml	29001 An unknown error occurred in Inquire Data Extraction.
InquireDataExtractionResources_EN.xml	29002 Worker - Error connecting to ECM.
InquireDataExtractionResources_EN.xml	29003 Worker - Error reading engine serial.
InquireDataExtractionResources_EN.xml	29004 Worker - Error creating image.
InquireDataExtractionResources_EN.xml	29005 Worker - Error looking up ECM Info.
InquireDataExtractionResources_EN.xml	29006 Worker - Error updating history.
InquireDataExtractionResources_EN.xml	29007 Worker - Error reading history data.
InquireDataExtractionResources_EN.xml	29008 Worker - Error in Do Operations.
InquireDataExtractionResources_EN.xml	29009 Worker - Error cancelling operations.
InquireDataExtractionResources_EN.xml	29010 Worker - Error renaming group.
InquireDataExtractionResources_EN.xml	29011 Worker - Error in thread ExecuteConnect.
InquireDataExtractionResources_EN.xml	29012 Worker - Error in thread ExecuteCreateImage.
InquireDataExtractionResources_EN.xml	29013 Worker - Error in thread ExecuteDoOperations.
InquireDataExtractionResources_EN.xml	29014 Worker - Error in helper connecting ECM.

InquireDataExtractionResources_EN.xml	29015 Worker - Error creating image header.
InquireDataExtractionResources_EN.xml	29016 Worker - Error creating image filename.
InquireDataExtractionResources_EN.xml	29017 Worker - Error resetting token.
InquireDataExtractionResources_EN.xml	29018 Worker - Error storing history.
InquireDataExtractionResources_EN.xml	29019 Worker - Error getting registry value.
InquireDataExtractionResources_EN.xml	29020 Worker - Error getting parameter value.
InquireDataExtractionResources_EN.xml	29021 Worker - Error in helper updating history.
InquireDataExtractionResources_EN.xml	29022 Worker - Error in firing progress update.
InquireDataExtractionResources_EN.xml	29023 UI - Error in load.
InquireDataExtractionResources_EN.xml	29024 UI - Error adding property page.
InquireDataExtractionResources_EN.xml	29025 UI - Error in UpdateProgress.
InquireDataExtractionResources_EN.xml	29026 UI - Error displaying Options.
InquireDataExtractionResources_EN.xml	29027 UI - Error connecting ECM.
InquireDataExtractionResources_EN.xml	29028 UI - Error creating image.
InquireDataExtractionResources_EN.xml	29029 UI - Error displaying history.
InquireDataExtractionResources_EN.xml	29030 UI - Error in AfterEdit.
InquireDataExtractionResources_EN.xml	29031 UI - Error executing double click on grid.
InquireDataExtractionResources_EN.xml	29032 UI - Error saving log messages.
InquireDataExtractionResources_EN.xml	29033 UI - Error cancelling operation.
InquireDataExtractionResources_EN.xml	29034 UI - Error during close.
InquireDataExtractionResources_EN.xml	29035 UI - Error reading ECM properties.
InquireDataExtractionResources_EN.xml	29036 UI - Error displaying engine info.
InquireDataExtractionResources_EN.xml	29037 UI - Error initializing dialog.
InquireDataExtractionResources_EN.xml	29038 UI - Error getting cell text.
InquireDataExtractionResources_EN.xml	29039 Old name not found to rename.
InquireDataExtractionResources_EN.xml	29040 Incorrect password entered for 3 times in a row.

InquireDataExtractionResources_EN.xml	29041 Error reading XML data for vehicle.
InquireDataExtractionResources_EN.xml	29042 Error loading vehicle data.
InquireDataExtractionResources_EN.xml	29043 Error writing vehicle history to file.
InquireDataExtractionResources_EN.xml	29044 Error creating vehicle history file.
InquireDataExtractionResources_EN.xml	29046 Error opening registry key for Connections.
InquireDataExtractionResources_EN.xml	29047 Error getting connection key value.
InquireDataExtractionResources_EN.xml	29048 Error getting connection string.
InquireDataExtractionResources_EN.xml	29049 Error populating connection information.
InquireDataExtractionResources_EN.xml	29050 Registry entry for connection name not found.
InquireDataExtractionResources_EN.xml	29051 Unknown connection type.
InquireDataExtractionResources_EN.xml	29052 Connection name not found.
InquireDataExtractionResources_EN.xml	29053 Error returned from Image Services.
InquireDataExtractionResources_EN.xml	29054 Error opening registry key for Templates.
InquireDataExtractionResources_EN.xml	29055 Connection Type not found in registry.
InsiteResources_EN.xml	10000 Unable to pass event to AddIn
InsiteResources_EN.xml	10001 Unable to load desired resource
InsiteResources_EN.xml	10002 Unable to load desired accelerator
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16100 An unknown exception occurred during the Intake Air Heater ECM test.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16101 A pointer to the Intake Air Heater Override Helper could not be gotten.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16102 Failure to start the test.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16103 An error occurred while writing a parameter to the ECM.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16104 An error occurred while reading a parameter.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16105 Invalid value for the 24 Volt Enable parameter.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	16106 The parameter being read had an invalid value.
IntakeAirHeaterOverrideGTIS45Resources_EN.xml	This action cannot be completed at this time. The ECM is currently locked by another active 16107 in progress and is not available.
J1922ControlHistoryResources_EN.xml	28500 An unknown error occurred.
J1922ControlHistoryResources_EN.xml	28501 An internal error occurred while initializing dialog.
J1922ControlHistoryResources_EN.xml	28502 An internal error occurred while populating grid.
J1922ControlHistoryResources_EN.xml	28503 An internal error occurred while resetting J1922.
J1922ControlHistoryResources_EN.xml	28504 An internal error occurred during printing.
J1922ControlHistoryResources_EN.xml	28505 An internal error occurred during print preview.
J1922ControlHistoryResources_EN.xml	28506 An internal error occurred during initialization.

J1922ControlHistoryResources_EN.xml	28507 An internal error occurred while initializing grid.
J1922ControlHistoryResources_EN.xml	28508 An internal error occurred in DataService QueryInterface.
J1922ControlHistoryResources_EN.xml	28509 An internal error occurred while reading token.
J1922ControlHistoryResources_EN.xml	28510 An internal error occurred while getting DataService.
J1922ControlHistoryResources_EN.xml	28511 An internal error occurred in IsJ1922Enabled.
J1922ControlHistoryResources_EN.xml	28512 An error occurred while attempting to reset the J1922 Control History.
J1939ControlHistoryResources_EN.xml	18700 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18702 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18703 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18704 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18701 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18705 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18706 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18707 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18708 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18709 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18710 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18711 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18712 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18713 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18714 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18715 System memory is low.
J1939ControlHistoryResources_EN.xml	18716 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18717 No J1939 Control History data is available for printing.
J1939ControlHistoryResources_EN.xml	18718 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18719 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18720 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18721 An error occurred with J1939 Control History.
J1939ControlHistoryResources_EN.xml	18722 Unable to reset J1939 Control History.
MaintenanceMonitorResources_EN.xml	18300 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18301 System memory is low.
MaintenanceMonitorResources_EN.xml	18302 No Maintenance Monitor data is available to be printing
MaintenanceMonitorResources_EN.xml	18303 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18304 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18305 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18306 An error occurred with Maintenance Monitor.

MaintenanceMonitorResources_EN.xml	18307 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18308 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18309 ECM images are read-only.
MaintenanceMonitorResources_EN.xml	18312 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18313 Maintenance Monitor cannot be reset.
MaintenanceMonitorResources_EN.xml	18314 This action cannot be completed at this time.
MaintenanceMonitorResources_EN.xml	18315 The Maintenance Monitor data may be inaccurate.
MaintenanceMonitorResources_EN.xml	18316 A communication error has occurred.
MaintenanceMonitorResources_EN.xml	18317 An error has occurred.
MaintenanceMonitorResources_EN.xml	18350 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18351 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18352 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18353 An error has occurred.
MaintenanceMonitorResources_EN.xml	18354 An error has occurred.
MaintenanceMonitorResources_EN.xml	18355 An error has occurred.
MaintenanceMonitorResources_EN.xml	18356 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18357 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18358 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18359 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18360 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18361 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18362 An error occurred in the ECM Fuel System Table Reset test.
MaintenanceMonitorResources_EN.xml	18363 System memory is low.
MaintenanceMonitorResources_EN.xml	18364 This action cannot be completed at this time.
MaintenanceMonitorResources_EN.xml	18365 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18366 An error occurred with Maintenance Monitor.
MaintenanceMonitorResources_EN.xml	18367 An error has occurred.
MaintenanceMonitorResources_EN.xml	18368 Engine Speed detected Maintenance Monitor cannot be reset.
OBDMonitorsResources_EN.xml	32000 An internal error has occurred in the OBDMonitors UI class.
OBDMonitorsResources_EN.xml	32001 A call to QueryInterface failed.
OBDMonitorsResources_EN.xml	32002 Failed to load a necessary resource.
OBDMonitorsResources_EN.xml	32003 An internal error occurred. The grid control could not be initialized.
OBDMonitorsResources_EN.xml	32004 A pointer evaluated to NULL.
OBDMonitorsResources_EN.xml	32005 An internal error occurred while setting up grid control default layout.
OBDMonitorsResources_EN.xml	32006 An internal error occurred while performing initialization of a flexGridHelper pointer
OBDMonitorsResources_EN.xml	An internal error occurred in ConnectionEstablished method while setting up the grid for a n
OBDMonitorsResources_EN.xml	32007 connection
OBDMonitorsResources_EN.xml	32008 An internal error occurred in ConnectionLost method while setting up the grid
OBDMonitorsResources_EN.xml	32009 An internal error occurred in OBDMonitorsDataAvailable method
OBDMonitorsResources_EN.xml	32010 An internal error occurred in populateGrid method
OBDMonitorsResources_EN.xml	32011 An internal error occurred in OnInitDialog method
OBDMonitorsResources_EN.xml	32012 An internal error occurred in refresh method

OBDMonitorsResources_EN.xml	32013 An internal error occurred in print method
OBDMonitorsResources_EN.xml	32014 An internal error occurred in printPreview method
OBDMonitorsResources_EN.xml	32015 An internal error occurred in pageSetup method
OBDMonitorsResources_EN.xml	32016 An internal error occurred in contextPrint method
OBDMonitorsResources_EN.xml	32017 An internal error occurred in contextRefreshAll method
OBDMonitorsResources_EN.xml	32500 An internal error has occurred in the OBDMonitors Worker class.
OBDMonitorsResources_EN.xml	32501 An internal error occurred while invoking the method
OBDMonitorsResources_EN.xml	32502 A call to QueryInterface failed while getting an IFaultsSystem interface
OBDMonitorsResources_EN.xml	32503 An internal error occurred in readOBDMonitorsData method
OBDMonitorsResources_EN.xml	32504 An internal error occurred in readOBDMonitorsDataForModule method
OBDMonitorsResources_EN.xml	32505 A call to CoCreateInstance failed
OBDMonitorsResources_EN.xml	32506 An internal error occurred in setMILONDistanceForModule method
OBDMonitorsResources_EN.xml	32507 An internal error occurred in readOBDMonitorsArray method
OBDMonitorsResources_EN.xml	32508 An internal error occurred in sortFaults method
OBDMonitorsResources_EN.xml	32509 An internal error occurred in sortFaultsByReadinessCode method
OBDMonitorsResources_EN.xml	32510 An internal error occurred in setFaultProperties method
OBDMonitorsResources_EN.xml	32511 An internal error occurred in associateInformation method
OBDMonitorsResources_EN.xml	32513 An internal error occurred in setMILOnTimeForModule method
OpenLoopModeLockInResources_EN.xml	16400 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16401 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16402 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16403 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16404 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16405 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16406 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16407 An internal error has occurred in the INSITE program.
OpenLoopModeLockInResources_EN.xml	16408 The connected ECM calibration does not have this operation enabled.
OptionsManagerResources_EN.xml	13995 An internal error has occurred in the INSITE program.
OptionsManagerResources_EN.xml	13996 An internal error has occurred in the INSITE program.
OptionsManagerResources_EN.xml	13997 An interna error has occurred in the INSITE program.
OptionsManagerResources_EN.xml	13994 Access Denied.
OptionsManagerResources_EN.xml	13989 An internal error has occurred in the INSITE program.
OptionsManagerResources_EN.xml	13988 An internal error has occurred in the INSITE program.
OptionsManagerResources_EN.xml	13987 An internal error has occurred in the INSITE program with the preference settings.

OptionsManagerResources_EN.xml	13986 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13982 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13983 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13984 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13985 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13981 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13980 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13979 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13978 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13977 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13976 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13974 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13975 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13973 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13972 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13971 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13970 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13969 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13968 An internal error has occurred in the INSITE program with the preference settings.

OptionsManagerResources_EN.xml	13967 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13966 An internal error has occurred in the INSITE program with the preference settings.
OptionsManagerResources_EN.xml	13965 An internal error has occurred in the INSITE program with the connection manager.
OptionsManagerResources_EN.xml	13964 The selected connection is active and cannot be deleted
OverrideResources_EN.xml	20600 Error while preparing the ECM to run this test..
OverrideResources_EN.xml	20601 Error while populating the list of monitored values.
OverrideResources_EN.xml	20602 Error while populating the list of available overrides for this test.
OverrideResources_EN.xml	The test could not restore the ECM to its proper state. Please turn the keyswitch off and restart the test
OverrideResources_EN.xml	20603 restart the test
OverrideResources_EN.xml	20604 Error initializing the test..
OverrideResources_EN.xml	20605 Error publishing events.
OverrideResources_EN.xml	20606 Error subscribing to events.
OverrideResources_EN.xml	20607 Error retrieving parameter from the collection of override parameters
OverrideResources_EN.xml	20608 Unable to obtain necessary interface in Override Tests
OverrideResources_EN.xml	20609 Error retrieving display name
OverrideResources_EN.xml	20610 Error retrieving display value
OverrideResources_EN.xml	20611 Error retrieving units.
OverrideResources_EN.xml	20612 Error retrieving status message.
OverrideResources_EN.xml	20613 Error retrieving instructions text..
OverrideResources_EN.xml	20614 Error getting data provider.
OverrideResources_EN.xml	20615 Error retrieving the current data.
OverrideResources_EN.xml	20616 Error retrieving the collection of monitor parameters.
OverrideResources_EN.xml	20617 Error retrieving the collection of override parameters.
OverrideResources_EN.xml	20618 Error changing override value in logic.
OverrideResources_EN.xml	20619 Error retrieving test duration value from Token APC_ti_startup_c.
PasswordRemovalResources_EN.xml	26100 An internal application error occurred. IDispatch failure occurred.
PasswordRemovalResources_EN.xml	26101 An internal application error occurred while communicating with the user interface.
PasswordRemovalResources_EN.xml	26102 Error while retrieving the Usage Counter interface from the Tool Security services
PasswordRemovalResources_EN.xml	26103 Error while retrieving the Usage Counts from the Tool Security services
PasswordRemovalResources_EN.xml	26104 Error while initializing interface pointers
PasswordRemovalResources_EN.xml	26105 Error while initializing interface pointers to display the window
PasswordRemovalResources_EN.xml	26106 Error while closing the window
PasswordRemovalResources_EN.xml	26107 Error while attempting to display the window
PasswordRemovalResources_EN.xml	26108 ECM Data Service not available
PasswordRemovalResources_EN.xml	26109 Error while obtaining password information
PasswordRemovalResources_EN.xml	26110 Error while resetting a password
PasswordRemovalResources_EN.xml	26111 Error attempting to communicate with the ECM
PasswordRemovalResources_EN.xml	26112 Error while decrementing the usage counts
PasswordRemovalResources_EN.xml	26113 Error while resetting a password
PasswordRemovalResources_EN.xml	26114 Error while resetting a password>
PasswordRemovalResources_EN.xml	26115 Error while resetting a password
PasswordRemovalResources_EN.xml	26116 Error while resetting a password
SecurityManagerResources_EN.xml	26300 An internal error has occurred in the INSITE program.
SecurityManagerResources_EN.xml	26301 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20200 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20201 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20202 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20203 An internal error has occurred in the INSITE program while running this test.



QSVGasTestSelectionResources_EN.xml	20204 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20205 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20206 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20207 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20208 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20209 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20210 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20211 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20212 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20213 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20214 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20215 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20216 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20217 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20218 An internal error has occurred in the INSITE program while running this test.
QSVGasTestSelectionResources_EN.xml	20219 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20220 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20221 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20222 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20223 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20224 Unable to find logic interface for a page
QSVGasTestSelectionResources_EN.xml	20225 Unable to create the logic for a page.
QSVGasTestSelectionResources_EN.xml	20226 Unable to initialize the logic for a page
QSVGasTestSelectionResources_EN.xml	20227 Failure in ECMDataService
QSVGasTestSelectionResources_EN.xml	20228 Page does not support necessary interface: IBranchManagerCallback
QSVGasTestSelectionResources_EN.xml	20229 Unable to find necessary item in the map.
QSVGasTestSelectionResources_EN.xml	20230 Unload of a page failed.
QSVGasTestSelectionResources_EN.xml	20231 Unable to retrieve module ID from the ECM.

QSVGasTestSelectionResources_EN.xml	20232 Unable to initialize the page manager.
QSVGasTestSelectionResources_EN.xml	20233 Unable to create helper.
QSVGasTestSelectionResources_EN.xml	20234 An error was encountered rolling back the test changes.
QSVGasTestSelectionResources_EN.xml	20235 Unable to switch the ECM between dev and def modes.
QSVGasTestSelectionResources_EN.xml	20236 An error was encountered committing back the test changes.
QSVGasTestSelectionResources_EN.xml	20237 Unable to write changes to the ECM because the engine was not shut down.
QSVGasTestSelectionResources_EN.xml	20300 An unexpected error occurred in Kilowatt Load Sensor Calibration.
QSVGasTestSelectionResources_EN.xml	20301 A string on the page failed to load.
QSVGasTestSelectionResources_EN.xml	20302 Unable to start the Kilowatt Load Sensor Calibration.
QSVGasTestSelectionResources_EN.xml	20303 Unable to properly initialize the test worker.
QSVGasTestSelectionResources_EN.xml	20304 Unable to register events to publish.
QSVGasTestSelectionResources_EN.xml	20305 Unable to subscribe to events.
QSVGasTestSelectionResources_EN.xml	20306 Unable to unpublish test events.
QSVGasTestSelectionResources_EN.xml	20307 Unable to unsubscribe from test events.
QSVGasTestSelectionResources_EN.xml	20308 Kilowatt Load Sensor Calibration failed to unload properly.
QSVGasTestSelectionResources_EN.xml	20309 Failed to read Kilowatt LoadSignal Current properly.
QSVGasTestSelectionResources_EN.xml	20310 Failed to read the Kilowatt Load Signal Current Low Load.
QSVGasTestSelectionResources_EN.xml	20311 Kilowatt Load Sensor Calibration encountered internal state errors.
QSVGasTestSelectionResources_EN.xml	20312 Failed to read the Engine Low Load.
QSVGasTestSelectionResources_EN.xml	20313 Failed to set the Engine Low Load.
QSVGasTestSelectionResources_EN.xml	20314 Failed to set the Engine High Load.
QSVGasTestSelectionResources_EN.xml	20315 Kilowatt Load Sensor Calibration failed to write the data to the ECM.
QSVGasTestSelectionResources_EN.xml	20400 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20401 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20402 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20403 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20404 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20405 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20406 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20407 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20408 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20409 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20410 An internal error has occurred in the INSITE program.

QSVGasTestSelectionResources_EN.xml	20411 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20412 An internal error has occurred in the INSITE program.
QSVGasTestSelectionResources_EN.xml	20413 INSITE encountered a problem creating the Gantt Chart for this test.
QSVGasTestSelectionResources_EN.xml	1 An internal error has occurred in the INSITE program.
RatedOverspeedProtectionResources_EN.xml	18800 An unidentified error occurred in "Rated Overspeed Protection".
RatedOverspeedProtectionResources_EN.xml	18801 Error in Initialization.
RatedOverspeedProtectionResources_EN.xml	18802 Error in Initialization.
RatedOverspeedProtectionResources_EN.xml	18803 Internal Error
RatedOverspeedProtectionResources_EN.xml	18804 Error in reading data
RatedOverspeedProtectionResources_EN.xml	18805 Error in initializing grid
RatedOverspeedProtectionResources_EN.xml	18806 Error in grid
RatedOverspeedProtectionResources_EN.xml	18807 Internal Error
RatedOverspeedProtectionResources_EN.xml	18808 Internal Error
RatedOverspeedProtectionResources_EN.xml	18809 Error in displaying help
RatedOverspeedProtectionResources_EN.xml	18810 Data could not be inserted in data grid
RatedOverspeedProtectionResources_EN.xml	18811 Data could not be inserted in log grid
RatedOverspeedProtectionResources_EN.xml	18812 Data could not be Destroyed
RatedOverspeedProtectionResources_EN.xml	18850 An unidentified error occurred in "Rated Overspeed Protection".
RatedOverspeedProtectionResources_EN.xml	18851 Internal Error in reading
RatedOverspeedProtectionResources_EN.xml	18852 Internal Error
RatedOverspeedProtectionResources_EN.xml	18853 Internal Error
RatedOverspeedProtectionResources_EN.xml	18854 Internal Error
RealTimeClockResources_EN.xml	18450 An unknown internal application error has occurred.
RealTimeClockResources_EN.xml	18451 Error while initializing the Real Time Clock Logic.
RealTimeClockResources_EN.xml	18452 Error while unloading the Real Time Clock Logic.
RealTimeClockResources_EN.xml	18453 Error while reading the value of a parameter from the ECM.
RealTimeClockResources_EN.xml	18454 Error while writing to the ECM.
RealTimeClockResources_EN.xml	18455 Error while setting the time in the ECM. Please turn the Key Switch off.
RealTimeClockResources_EN.xml	18456 Error while setting the time in the ECM
RealTimeClockResources_EN.xml	You cannot perform this operation, either because you do not have the appropriate tool level
RealTimeClockResources_EN.xml	18457 or user level, or because the ECM is password protected.
RealTimeClockResources_EN.xml	18458 Error loading the licenses for Real Time Clock
RealTimeClockResources_EN.xml	18459 Error checking the security level
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20827 Error occurred while extracting device names from device address.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20920 Error occurred while checking Test Enable.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20922 Error occurred while checking Test Enable.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20923 Error occurred while getting max number of Blocked Devices.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20924 Error occurred while getting Supported Device Names.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20925 Error occurred while getting Supported list of Blocked Devices.

SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20926 Error occurred while setting Device Block Status.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20927 Error occurred while Initializing UI controls.
SAEJ1939DataLinkControlTestGTIS45Resources_EN.xml	20928 Error occurred while Initializing Flex Grid on UI.
SAEJ1939PowerTrainControlTest_EN.xml SpecialFeatureResources_EN.xml SpecialFeatureResources_EN.xml	16615 An internal error has occurred in the INSITE program. 12001 INSITE has detected no Engine Speed. Please start the engine, and restart the test. 12002 INSITE has detected Vehicle Speed. Please reduce speed to zero, and restart the test.
SpecialFeatureResources_EN.xml	12003 INSITE has detected Engine Speed. Please reduce Engine Speed to zero, and restart the test.
SpecialFeatureResources_EN.xml	12004 INSITE has detected both Engine Speed and Vehicle Speed. Please reduce both speeds to zero, and restart the test.
SpecialFeatureResources_EN.xml	12005 Test stopped, no engine speed detected.
SpecialFeatureResources_EN.xml	12006 Test stopped, vehicle speed detected. Stop vehicle and restart test.
SpecialFeatureResources_EN.xml	12007 Engine Speed detected. Shutdown engine, key on, and restart test.
SpecialFeatureResources_EN.xml	12008 This test is not supported with the current calibration and hardware setup.
SpecialFeatureResources_EN.xml	12009 Allows the fan to be engaged at full speed for an adjustable amount of time
SpecialFeatureResources_EN.xml	12010 INSITE has detected Engine Speed is less than 600 rpm.
SpecialFeatureResources_EN.xml	12011 The Fuel Lift Pump Override Test is not available for this engine. No fuel lift pump is installed.
SpecialFeatureResources_EN.xml	12012 Low battery voltage detected. Troubleshoot the low battery voltage fault code before proceeding with this test.
SpecialFeatureResources_EN.xml	12013 Other Device is controlling Engine. Disconnect appropriate datalink.
SpecialFeatureResources_EN.xml	12014 The test was not started because Engine Speed was not greater than 600 rpm.
SpecialFeatureResources_EN.xml	12015 Vehicle is moving. Stop vehicle and restart test.
SpecialFeatureResources_EN.xml	12016 PTO is active. Turn off PTO.
SpecialFeatureResources_EN.xml	12017 Cummins Service Tool is overriding TVO State. Disconnect appropriate tool.
SpecialFeatureResources_EN.xml	12018 Limp home state active. Check for active Fault Codes.
SpecialFeatureResources_EN.xml	12019 Governor type is Variable Speed. Change to Automotive and restart test.
SpecialFeatureResources_EN.xml	12020 Cruise Control is active. Turn off Cruise Control.
SpecialFeatureResources_EN.xml	12021 Vehicle is moving. Stop vehicle and restart test.
SpecialFeatureResources_EN.xml	12022 Increase engine RPM by increasing % Accelerator.
SpecialFeatureResources_EN.xml	12023 Decrease engine RPM by decreasing % Accelerator.
SpecialFeatureResources_EN.xml	12024 The test was not started because the Vehicle Speed was greater than 0.
SpecialFeatureResources_EN.xml	12025 The test was aborted because the Vehicle Speed was greater than 0.
SpecialFeatureResources_EN.xml	12026 Engine Protection activated. Check for active fault codes.
SpecialFeatureResources_EN.xml	12027 Decrease engine RPM by decreasing % Accelerator.
SpecialFeatureResources_EN.xml	12028 Other Device is controlling Engine. Disconnect appropriate datalink.
SpecialFeatureResources_EN.xml	12029 Vehicle is moving. Stop vehicle and restart test.
SpecialFeatureResources_EN.xml	12030 Please wait.
SpecialFeatureResources_EN.xml	12031 Cummins Service Tool is overriding TVO State. Disconnect appropriate tool.
SpecialFeatureResources_EN.xml	12032 Engine Break is ON. Turn OFF Engine Break.
SpecialFeatureResources_EN.xml	12033 Decrease engine RPM by decreasing % Accelerator.
SpecialFeatureResources_EN.xml	12034 Engine Stopped. Start engine and restart test.
SpecialFeatureResources_EN.xml	12035 The test was aborted because the Engine Speed was less than 600 rpm.
SpecialFeatureResources_EN.xml	12036 Accelerator Interlock is active. Correct Accelerator Interlock.
SpecialFeatureResources_EN.xml	12037 Alternate Torque is active. Turn off Alternate Torque.
SpecialFeatureResources_EN.xml	12038 The current calibration does not support the Eaton Top 2 Autoshift Feature.
SpecialFeatureResources_EN.xml	12039 The test was not started because the vehicle speed sensor signal was lost.
SpecialFeatureResources_EN.xml	12040 The test was not started because the vehicle speed sensor was in an unknown state.
SpecialFeatureResources_EN.xml	12041 The test was aborted because the vehicle speed sensor signal was lost.
SpecialFeatureResources_EN.xml	12042 The test was aborted because the vehicle speed sensor was in an unknown state.
SpecialFeatureResources_EN.xml	12043 An unexpected response was received when accessing this feature.
StarterLockoutTestGTIS45Resources_EN.xml	16568 Failure while writing data to ECM Services.
StarterLockoutTestGTIS45Resources_EN.xml	16569 Failed to launch help.
StarterLockoutTestGTIS45Resources_EN.xml	16570 This test is not supported by the current calibration.
StarterLockoutTestGTIS45Resources_EN.xml	16520 Failed to write driver token.
StarterLockoutTestGTIS45Resources_EN.xml	16521 Failed to write start-stop token.
StarterLockoutTestGTIS45Resources_EN.xml	16523 Failed to get TIS support
StarterLockoutTestGTIS45Resources_EN.xml	16524 Failed to get test enable
TestContainerResources_EN.xml	15001 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15002 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15003 An internal error has occurred in the INSITE program.

TestContainerResources_EN.xml	15004 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15005 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15006 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15007 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15008 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15009 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15010 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15011 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15012 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15013 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15014 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15015 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15016 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15017 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15018 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15019 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15020 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15021 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15022 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15023 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15024 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15025 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15026 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15027 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15028 An internal error has occurred in the INSITE program.

TestContainerResources_EN.xml	15029 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15030 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15031 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15032 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15033 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15034 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15035 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15036 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15037 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15038 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15039 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15040 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15041 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15042 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15043 INSITE is unable to complete the test.
TestContainerResources_EN.xml	15502 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15503 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15504 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15505 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15506 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15507 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15508 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15509 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15510 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15511 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15512 An internal error has occurred in the INSITE program.

TestContainerResources_EN.xml	15044 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15045 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15514 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15515 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15046 An internal error has occurred in the INSITE program.
TestContainerResources_EN.xml	15047 INSITE was unable to stop the test. A key off will be required to stop the test.
TripInformationResources_EN.xml	8533 The current user is not permitted to perform Trip Information Reset.
TripInformationResources_EN.xml	8534 The current tool level is not adequate to perform Trip Information Reset.
TripInformationResources_EN.xml	8535 The ECM is password protected. Trip Information cannot be reset.
TripInformationResources_EN.xml	8536 The application is busy reading the ECM for current Trip Information.
TripInformationResources_EN.xml	8537 An error has occurred during Trip Information Reset.
TripInformationResources_EN.xml	8538 Trip Information cannot be reset with the engine running.
TripInformationResources_EN.xml	8539 An error occurred while accessing the registry.
VGTActuatorResources_EN.xml	16800 An unexpected error occurred in the VGT Turbocharger Test.
VGTActuatorResources_EN.xml	16801 An invalid delay was specified.
VGTActuatorResources_EN.xml	16802 An error occurred and the Turbocharger actuator could not be opened
VGTActuatorResources_EN.xml	16803 An error occurred while the page was unloading
VGTActuatorResources_EN.xml	16804 An error occurred while attempting to unsubscribe to mapped events
VGTActuatorResources_EN.xml	16805 An error occurred while attempting to subscribe to mapped events
VGTActuatorResources_EN.xml	16806 An error occurred while attempting to locate the Logic interface
VGTActuatorResources_EN.xml	16807 An error occurred while attempting to Initialize the page component
VGTActuatorResources_EN.xml	16808 An error occurred while attempting to Start the test
VGTActuatorResources_EN.xml	16809 An error occurred while attempting to Stop the test
VGTActuatorResources_EN.xml	16810 One or more of the PreConditions have failed.
VGTActuatorResources_EN.xml	16811 An error occurred while attempting to open the Turbocharger actuator.
VGTActuatorResources_EN.xml	16812 An error occurred while attempting to close the Turbocharger actuator.
VGTActuatorResources_EN.xml	16813 An error occurred while attempting to open the Turbocharger actuator.
VGTActuatorResources_EN.xml	16814 An error occurred while attempting to close the Turbocharger actuator.
VGTActuatorResources_EN.xml	16815 An error occurred while attempting to create the thread.
VGTActuatorResources_EN.xml	16816 An error occurred while attempting to start the ECMPoller.
VGTActuatorResources_EN.xml	16817 The engine speed was greater than zero.
VGTActuatorResources_EN.xml	16818 An error occurred while attempting to unPublish mapped events.
VGTActuatorResources_EN.xml	16819 Engine speed detected. Shutdown engine and restart test.
VGTActuatorResources_EN.xml	16820 Precondition failed: T_VGA_Swingvane_Enable is disabled. Cannot start test.
VGTActuatorResources_EN.xml	16821 Precondition failed: T_VGT_Pneumatic_Control_Enable is enabled. Cannot start test.
VGTActuatorResources_EN.xml	16822 Precondition failed: Turbocharger Speed Faults are active. Cannot start test.
VGTActuatorResources_EN.xml	16823 Precondition failed: Turbocharger Speed Faults are active. Cannot start test.
VGTActuatorResources_EN.xml	16824 Precondition failed: Turbocharger Speed Faults are active. Cannot start test.
VGTActuatorResources_EN.xml	Precondition failed: VGT Actuator Position Circuit - Shorted high Fault is active. Cannot start test.
VGTActuatorResources_EN.xml	16825 test.
VGTActuatorResources_EN.xml	Precondition failed: VGT Actuator Position Circuit - Shorted low Fault is active. Cannot start test.
VGTActuatorResources_EN.xml	16826 test.
VGTActuatorResources_EN.xml	16827 Failed to properly communicate with the ECM.
VGTActuatorResources_EN.xml	16828 An error occurred while attempting to stop the test.
VGTActuatorResources_EN.xml	16829 Precondition failed: Turbocharger Air Shutoff Valve Faults are active. Cannot start test.
VGTActuatorResources_EN.xml	16830 Precondition failed: Turbocharger Air Shutoff Valve Faults are active. Cannot start test.
VGTActuatorResources_EN.xml	Turbocharger control valve circuit fault detected. Troubleshoot the turbocharger control valve circuit fault code before proceeding with this test.
VGTActuatorResources_EN.xml	16831 circuit fault code before proceeding with this test.
VGTActuatorResources_EN.xml	16832 Precondition failed: Turbocharger Control Valve Faults are active. Cannot start test.
VGTActuatorResources_EN.xml	16833 Turbocharger control shutoff valve circuit fault detected.
VGTActuatorResources_EN.xml	16834 Turbocharger control shutoff valve circuit fault detected.
VGTActuatorResources_EN.xml	16835 Turbocharger control valve circuit fault detected.
VGTActuatorResources_EN.xml	16836 Turbocharger control valve circuit fault detected.

VGTActuatorResources_EN.xml WorkOrdersResources_EN.xml	16837 Turbocharger position sensor circuit fault detected. 10400 Unknown error in Work Orders.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10401 An internal error occurred while transferring the template to the ECM. Unable to proceed. The tool level is inadequate to write to the ECM, or the ECM is password protected.
WorkOrdersResources_EN.xml	10403 An internal error occurred while creating the image.
WorkOrdersResources_EN.xml	10404 An internal error occurred while attempting to connect to the image.
WorkOrdersResources_EN.xml	10405 An internal error occurred while initializing the system based on the connection.
WorkOrdersResources_EN.xml	10406 An internal error occurred while converting the image to a template.
WorkOrdersResources_EN.xml	10407 An internal error occurred while retrieving system information based on the connection.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10408 An internal error occurred while initializing the system based on the connection. 10409 An internal error occurred while initializing the system based on the connection. 10410 Unable to proceed. The current user is not permitted to perform this operation. 10411 An unknown error occurred during image creation.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10412 INSITE failed to start the image creation process. INSITE failed to transfer the template to the module. A template created from a simulator can only be written to a simulator.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	INSITE failed to transfer the template to the module. The module is not in a state which allows template transfers. 10415 INSITE failed to transfer the template to the module. The template could not be found. 10416 INSITE failed to transfer the template to the module. An unknown error occurred.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	INSITE failed to transfer the template because the License Type required is not active or the ECM is locked with a password. There is not enough disk space available to create the image. Please make more disk space available. The module is currently in a mode which does not support imaging. Please ensure that no ECM Tests are running.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10420 An internal error occurred while initializing modules for the connected ECM. 10421 An internal error occurred while deleting the image. 10422 An internal error occurred while deleting the template.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10423 Unable to find this Work Order in the Work Order File, Your Work Order File is Corrupted. 10424 The Import operation failed.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10425 The Export operation failed. 10426 The Import operation failed for the following file(s).
WorkOrdersResources_EN.xml	10427 An internal error occurred while initializing WorkOrders for the connected ECM.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10428 An internal error occurred in WorkOrders activation. INSITE failed to transfer the template to the module. The ECM's Engine Speed is Greater than Zero.
WorkOrdersResources_EN.xml	10430 An internal error occurred while attempting to print or print preview.
WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml WorkOrdersResources_EN.xml	10431 The ECM Image was not created successfully due to a loss of ECM Communication. INSITE has detected a problem with the image or template selected. INSITE can no longer connect to this image or template. 10433 An internal error occurred while extracting workOrder image.



WorkOrdersResources_EN.xml	WorkOrderUpgrade.xml is missing or corrupted. All previous version ECM Images or Templates will not be upgraded. 10434 Please reinstall INSITE and retry. If problem persists, please contact the local distributor.
WorkOrdersResources_EN.xml	10502 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10511 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10615 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10617 An internal error occurred while opening INSITE
WorkOrdersResources_EN.xml	10503 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10504 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10505 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10506 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10507 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10508 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10509 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10510 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10611 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10612 An internal error occurred while upgrading Work Orders
WorkOrdersResources_EN.xml	10613 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10614 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10616 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10618 An internal error occurred while opening INSITE
WorkOrdersResources_EN.xml	10619 An internal error occurred while opening INSITE
WorkOrdersResources_EN.xml	10620 An internal error occurred while opening INSITE
WorkOrdersResources_EN.xml	10621 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	10622 An internal error occurred while opening Work Orders
WorkOrdersResources_EN.xml	INSITE is unable to complete the selected operation because the target file could not be 10623 found.
WorkOrdersResources_EN.xml	10627 TEMPLATE_NAME contains invalid data and cannot be transferred to ECM
WorkOrdersResources_EN.xml	This image/template was created by another user under a different Windows account, and c 10628 only be accessed by the Windows administrator.

WorkOrdersResources_EN.xml	10629 INSITE is unable to save the exported files.
WorkOrdersResources_EN.xml	The selected images cannot be exported. The current license does not match the engine 10630 programs.
UreaDoserPumpAirSoleniodResource_EN.xml	The ECM has detected an invalid state for the test to run. Please troubleshoot any fault cod 35940 that may be active before running this test. ECM Repsonse Code: XXX
UreaDoserPumpAirSoleniodResource_EN.xml	35941 The test has an unrecognized status.
UreaDoserPumpAirSoleniodResource_EN.xml	35942 The ECM values for "Click Time" have not been set correctly in the calibration.
UreaDoserPumpAirSoleniodResource_EN.xml	35943 The calibration is unable to perform this test.
UreaDoserPumpOverrideResource_EN.xml	The ECM has detected an invalid state for the test to run. Please troubleshoot any fault cod 35920 that may be active before running this test. ECM Repsonse Code: XXX
UreaDoserPumpOverrideResource_EN.xml	The test status parameter has a value outside of the expected range. The value of the test 35921 status parameter is equal to X.
UreaDoserPumpOverrideResource_EN.xml	This test is not supported by the current calibration. The calibration does not have all of the 35922 parameters needed to run this test.
UreaDoserSystemHeaterResource_EN.xml	The ECM has detected an invalid state for the test to run. Please troubleshoot any fault coc 35900 that may be active before running this test. ECM Repsonse Code: XXX
UreaDoserSystemHeaterResource_EN.xml	The test status parameter has a value outside of the expected range. The value of the test 35901 status parameter is equal to X.
CalibrationSelectionResources_EN.xml	27200 INSITE could not retrieve saved calibration authorization passwords.
CalibrationSelectionResources_EN.xml	27201 INSITE could not retrieve saved calibration authorization passwords.
CalibrationSelectionResources_EN.xml	27202 INSITE could not retrieve saved calibration authorization passwords.
CalibrationSelectionResources_EN.xml	27204 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27205 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27206 INSITE is unable to retrieve Certification Code information.
CalibrationSelectionResources_EN.xml	27207 INSITE is unable to retrieve Certification Code information.
CalibrationSelectionResources_EN.xml	27208 INSITE is unable to retrieve ECM part number information from the database.
CalibrationSelectionResources_EN.xml	27209 INSITE is unable to retrieve Calibration Selection information from the database.
CalibrationSelectionResources_EN.xml	27210 INSITE is unable to retrieve Calibration Property information from the database.
CalibrationSelectionResources_EN.xml	27211 INSITE is unable to retrieve Calibration Property information from the database.
CalibrationSelectionResources_EN.xml	27212 INSITE is unable to retrieve Supersession information from the database.
CalibrationSelectionResources_EN.xml	27213 INSITE is unable to retrieve Supersession information from the database.
CalibrationSelectionResources_EN.xml	27214 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27215 INSITE is unable to retrieve Calibration Date information from the database.
CalibrationSelectionResources_EN.xml	27216 INSITE is unable to retrieve information from the calibration database.

CalibrationSelectionResources_EN.xml	27217 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27218 INSITE is unable to retrieve Compatible Engine information from the database.
CalibrationSelectionResources_EN.xml	27219 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27220 INSITE is unable to retrieve Compatible FR Option information from the database.
CalibrationSelectionResources_EN.xml	27221 INSITE is unable to retrieve Compatible Calibration information from the database.
CalibrationSelectionResources_EN.xml	27222 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27223 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27224 INSITE is unable to retrieve Compatible GCM Calibration information from the database.
CalibrationSelectionResources_EN.xml	27225 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27226 INSITE is unable to retrieve Supersession information from the database.
CalibrationSelectionResources_EN.xml	27227 INSITE is unable to retrieve information from the calibration database.
CalibrationSelectionResources_EN.xml	27228 INSITE is unable to retrieve information from the (name) calibration database.
CalibrationSelectionResources_EN.xml	27229 INSITE is unable to retrieve Query Version information from the database.
CalibrationSelectionResources_EN.xml	27230 INSITE is unable to retrieve ECM part number information from the database.
CalibrationSelectionResources_EN.xml	27231 The Programmable Datalink Device could not communicate with the datalink driver.
CalibrationSelectionResources_EN.xml	27232 The ECM could not communicate with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27233 The ECM could not communicate with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27234 The calibration was not found on the selected drive.
CalibrationSelectionResources_EN.xml	27235 Calibration selection was unable to uncompress the calibration file.
CalibrationSelectionResources_EN.xml	The Reflash Utility cannot download the calibration at this time because a valid calibration transfer license was not found. Ensure there is a valid license for the Reflash Utility.
CalibrationSelectionResources_EN.xml	27236
CalibrationSelectionResources_EN.xml	27237 Reflash Utility failed. Unknown error has happened.
CalibrationSelectionResources_EN.xml	27238 The Programmable Datalink Device could not communicate with the Reflash Utility.
CalibrationSelectionResources_EN.xml	27239 The calibration download failed. No response from the Programmable Datalink Device.
CalibrationSelectionResources_EN.xml	INSITE cannot download the calibration at this time because INSITE cannot currently write to 27240 the PDD.
CalibrationSelectionResources_EN.xml	27241 The ECM could not communicate with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27242 The ECM could not communicate with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27243 The ECM could not communicate with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27244 The selected calibration is not compatible with the connected Programmable Datalink Device.
CalibrationSelectionResources_EN.xml	27245 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27246 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27247 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27248 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27249 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller.

CalibrationSelectionResources_EN.xml	27250 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller.
CalibrationSelectionResources_EN.xml	27251 The datalink adapter connected does not support RP1210.
CalibrationSelectionResources_EN.xml	27252 INSITE could not start the Reflash Utility.
CalibrationSelectionResources_EN.xml	27253 The Reflash Utility cannot read the calibration file at this time. The Reflash Utility cannot download the calibration at this time because no compatible ECU 27254 was identified.
CalibrationSelectionResources_EN.xml	27255 The ECM lost communication with the Aftertreatment Diesel Exhaust Fluid Controller. The Reflash Utility cannot download the calibration at this time because a valid INSITE 27256 calibration transfer license was not found.
CalibrationSelectionResources_EN.xml	27257 Calibration download failed due to invalid set up of QST30.
CalibrationSelectionResources_EN.xml	27258 No smart Device was found. Please check the setup and try again. INSITE cannot search for updates for the connected ECM at this time because INSITE was 27259 unable to locate a valid calibration transfer license.
CalibrationSelectionResources_EN.xml	27260 INSITE is unable to calibrate the selected PDD due to the system configuration. INSITE cannot currently read the ECM parameters from the connected ECM. Please contact 40400 technical support.
KnockCountResetResources_EN.xml	
KnockCountResetResources_EN.xml	40401 INSITE cannot write to the Knock Count Reset parameter. Please contact technical support
HighPressureCommonRailInjectorSetup_EN.xml	INSITE cannot currently read the ECM parameters from the connected ECM. Please contact 40700 technical support.
HighPressureCommonRailInjectorSetup_EN.xml	You cannot perform this operation, either because you do not have the appropriate tool level 40713 or user level, or because the ECM is password protected.
HighPressureCommonRailInjectorSetup_EN.xml	40712 Error loading the licenses for High Pressure Common Rail Injector Setup
HighPressureCommonRailInjectorSetup_EN.xml	40714 Error checking the security level
DataMonitorLoggerResources_EN.xml	9901 An internal error has occurred in the INSITE .program with Print Preview
DataMonitorLoggerResources_EN.xml	9902 An Internal error has occurred in the INSITE program while Printing.
AdefSystemLeakTestResources_EN.xml	42000 INSITE was unable to stop the test. A key off will be required to stop the test.
AdefSystemLeakTestResources_EN.xml	42001 An internal error has occurred.
AdefSystemLeakTestResources_EN.xml	42002 An internal error has occurred.
AdefSystemLeakTestResources_EN.xml	42003 An internal error has occurred.
AftertreatmentSCRcatalystDesulphurizationResources_EN.xml	INSITE cannot read the ECM parameters when connected to the ECM. Please contact 43000 technical support.
SingleBankCutout_EN.xml	45000 "NameError45000" INSITE cannot read the ECM parameters when connected to the ECM. Please contact 46000 technical support.
FuelInjectorReset_EN.xml	INSITE cannot read the ECM parameters when connected to the ECM. Please contact 47000 technical support.
FuelInjectorReset_EN.xml	One or more injectors have not been reset. A key off is required to complete the process or 47001 the injectors that were successfully reset.
InjectorPerformanceTest_EN.xml	INSITE cannot currently read the ECM parameters from the connected ECM. Please contact 48000 technical support.
InjectorPerformanceTest_EN.xml	48001 An internal error occurred while getting enumeration.
InjectorPerformanceTest_EN.xml	There is not enough disk space available to create the log file. Please contact the local 48002 administrator.
InjectorPerformanceTest_EN.xml	The user does not have sufficient access permissions to create the log file. Please contact 48003 local administrator.
InjectorPerformanceTest_EN.xml	48004 Unknown error occurred while saving test data. Please contact technical support.
InsiteResources_EN.xml	-3001 An invalid INSITE application is detected. INSITE will now shutdown.

InsiteResources_EN.xml	-3002	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3003	A licensing error has occurred.
InsiteResources_EN.xml	-3004	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3005	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3006	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3007	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3008	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3009	An unexpected response was received when accessing the INSITE license.
InsiteResources_EN.xml	-3010	An unexpected response was received when accessing the INSITE license.
InsiteResources_EN.xml	-3011	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-3012	INSITE was unable to access the licensing information.
InsiteResources_EN.xml	-9999	An unexpected error occurred with INSITE licensing.
		The installed INSITE Data Pack <<Data Pack version>> and INSITE <<INSITE version>> a 49000 incompatible.
InsiteResources_EN.xml	-3017	An active license is required to use this tool functionality. Please contact your local distributor to obtain an Activation Key for this engine model.
InsiteResources_EN.xml	-3018	A Basic license is required. Please activate a Basic license using the License Configuration Manager.
InsiteResources_EN.dll	-3022	INSITE will not open because the Cummins License Configuration Tool Software License Agreement was declined.
InsiteResources_EN.xml	-3023	An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50001	An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50002	An internal error has occurred in the INSITE program.
DiagnosticFramework.dll	50003	An internal error has occurred in the INSITE program.
KernelServiceProvider.dll	50004	An internal error has occurred in the INSITE program.
*.dlls deployed by INSITE Installer	50004	An internal error has occurred in the INSITE program.
*.dlls deployed by INSITE Installer	50004	An internal error has occurred in the INSITE program.
*.dlls deployed by INSITE	50005	An unexpected error occurred. INSITE shall now close.

InsiteResources_EN.dll	50051 An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50076 An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50101 An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50126 An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50151 An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50176 An internal error has occurred in the INSITE program.
InsiteResources_EN.dll	50201 An internal error has occurred in the INSITE program.
N/A	50501 An internal error has occurred in the INSITE program.
Metatdata Resource	50502 An internal error has occurred in the INSITE program.
Metatdata Resource	50503 An internal error has occurred in the INSITE program.
DynamicEnumeration	50504 An internal error has occurred in the INSITE program.
Metadata.accdb	50505 An internal error has occurred in the INSITE program.
FnPDatabase.mdb	50506 An internal error has occurred in the INSITE program.

N/A	50507 An internal error has occurred in the INSITE program.
pcfg	50508 An internal error has occurred in the INSITE program.
pcfg	50509 An internal error has occurred in the INSITE program.
pcfg	50510 An internal error has occurred in the INSITE program.
ECMServicesConfiguration	50511 An internal error has occurred in the INSITE program.
N/A	50512 An internal error has occurred in the INSITE program.
N/A	50513 An internal error has occurred in the INSITE program.
INSITE Resource	50514 An internal error has occurred in the INSITE program.
INSITE Resource	50515 An internal error has occurred in the INSITE program.
DynamicEnumeration	50516 An internal error has occurred in the INSITE program.
CCServices.dll	50601 An internal error has occurred in the INSITE program.
CCServices.dll	50602 An internal error has occurred in the INSITE program.
CommunicationServices.dll	50603 An internal error has occurred in the INSITE program.

CommunicationServices.dll	50604 An internal error has occurred in the INSITE program.
ConnectionServices.dll	50605 An internal error has occurred in the INSITE program.
ConnectionServices.dll	50606 An internal error has occurred in the INSITE program.
CustomEvaluators.dll	50607 An internal error has occurred in the INSITE program.
CustomEvaluators.dll	50608 An internal error has occurred in the INSITE program.
DataServices.dll	50609 An internal error has occurred in the INSITE program.
DataServices.dll	50610 An internal error has occurred in the INSITE program.
ECMServices.dll	50611 An internal error has occurred in the INSITE program.
ECMServices.dll	50612 An internal error has occurred in the INSITE program.
ECMServicesAPI.dll	50613 An internal error has occurred in the INSITE program.
ECMServicesAPI.dll	50614 An internal error has occurred in the INSITE program.
ECMServicesCommonTypes.dll	50615 An internal error has occurred in the INSITE program.
ECMServicesCommonTypes.dll	50616 An internal error has occurred in the INSITE program.



EvaluatorServices.dll	50617 An internal error has occurred in the INSITE program.
EvaluatorServices.dll	50618 An internal error has occurred in the INSITE program.
ICLServices.dll	50619 An internal error has occurred in the INSITE program.
ICLServices.dll	50620 An internal error has occurred in the INSITE program.
ICL.dll	50621 An internal error has occurred in the INSITE program.
ICL.dll	50622 An internal error has occurred in the INSITE program.
ImageServices.dll	50623 An internal error has occurred in the INSITE program.
ImageServices.dll	50624 An internal error has occurred in the INSITE program.
INSITEImageReader.dll	50625 An internal error has occurred in the INSITE program.
INSITEImageReader.dll	50626 An internal error has occurred in the INSITE program.
MetadataServices.dll	50627 An internal error has occurred in the INSITE program.
MetadataServices.dll	50628 An internal error has occurred in the INSITE program.
MonitorServices.dll	50629 An internal error has occurred in the INSITE program.

MonitorServices.dll	50630 An internal error has occurred in the INSITE program.
PCLServices.dll	50631 An internal error has occurred in the INSITE program.
PCLServices.dll	50632 An internal error has occurred in the INSITE program.
MsgManager.dll	50633 An internal error has occurred in the INSITE program.
MsgManager.dll	50634 An internal error has occurred in the INSITE program.
CILCompressionUtilitiesLib.dll	50635 An internal error has occurred in the INSITE program.
CILCompressionUtilitiesLib.dll	50636 An internal error has occurred in the INSITE program.
DPFRestrictionTest.xml	51000 An internal error occurred while getting enumeration. There is not enough disk space available to create the log file. Please contact the local administrator.
DPFRestrictionTest.xml	51001 administrator.
DPFRestrictionTest.xml	The user does not have sufficient access permissions to create the log file. Please contact t
DPFRestrictionTest.xml	51002 local administrator.
DPFRestrictionTest.xml	51003 Unknown error occurred while saving test data. Please contact technical support.
InsiteResources_*.xml	10005 An internal error has occurred. INSITE will now close.